

# **NAT-102 Series User's Manual**

---

**Version 1.0, December 2021**

[www.moxa.com/product](http://www.moxa.com/product)



© 2021 Moxa Inc. All rights reserved.

# NAT-102 Series User's Manual

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

## Copyright Notice

© 2021 Moxa Inc. All rights reserved.

## Trademarks

The MOXA logo is a registered trademark of Moxa Inc.  
All other trademarks or registered marks in this manual belong to their respective manufacturers.

## Disclaimer

Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.

Moxa provides this document as is, without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.

Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.

This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

## Technical Support Contact Information

[www.moxa.com/support](http://www.moxa.com/support)

### **Moxa Americas**

Toll-free: 1-888-669-2872  
Tel: +1-714-528-6777  
Fax: +1-714-528-6778

### **Moxa Europe**

Tel: +49-89-3 70 03 99-0  
Fax: +49-89-3 70 03 99-99

### **Moxa India**

Tel: +91-80-4172-9088  
Fax: +91-80-4132-1045

### **Moxa China (Shanghai office)**

Toll-free: 800-820-5036  
Tel: +86-21-5258-9955  
Fax: +86-21-5258-5505

### **Moxa Asia-Pacific**

Tel: +886-2-8919-1230  
Fax: +886-2-8919-1231

# Table of Contents

<b>1. Introduction</b>	<b>1-1</b>
Overview	1-2
Package Checklist	1-2
Features	1-2
Quick and User-friendly Access Control	1-2
Industrial-grade and Ultra-compact Design	1-2
<b>2. Getting Started</b>	<b>2-1</b>
RS-232 Console Configuration (115200, None, 8, 1, VT100)	2-2
Using Telnet to Access the Industrial NAT Device's Console	2-4
Using a Web Browser to Configure the Industrial NAT Device	2-6
<b>3. Device Summary and Wizard</b>	<b>3-1</b>
Device Summary	3-2
Wizard	3-4
Step 1: Welcome	3-4
Step 2: Network Configuration	3-4
Step 3: NAT Settings	3-5
Step 4: Device Lockdown	3-5
Step 5: Setup Complete!	3-6
<b>4. System</b>	<b>4-1</b>
System Management	4-2
Device Information	4-2
Firmware Upgrade	4-3
Configuration Backup and Restore	4-3
Account Management	4-5
User Account	4-5
Password Policy	4-8
Management Interface	4-8
User Interface	4-9
Time	4-11
System Time	4-11
Time Zone	4-12
<b>5. Network Configuration</b>	<b>5-1</b>
Port	5-2
Port Settings	5-2
Layer 2 Switching	5-4
VLAN	5-4
MAC Address Table	5-10
Layer 3 Interfaces	5-11
<b>6. Network Service</b>	<b>6-1</b>
DHCP Server	6-2
General	6-2
DHCP	6-2
MAC-based IP Assignment	6-4
Port-based IP Assignment	6-6
Lease Table	6-8
<b>7. Routing &amp; NAT</b>	<b>7-1</b>
Unicast Routing	7-2
Static Routes	7-2
Routing Table	7-3
NAT Settings	7-4
NAT Concept	7-4
1-to-1 NAT Overview	7-4
1-to-1 NAT	7-6
N-to-1 NAT	7-9
PAT (Port Address Translation)	7-10
Advance	7-14
<b>8. Firewall</b>	<b>8-1</b>
Policy Concept	8-2
Layer 3 Policy	8-2
Create a New Firewall Policy	8-3
Automation Profile	8-6
<b>9. Security</b>	<b>9-1</b>
Device Security	9-2
Login Policy	9-2
Trusted Access	9-3

SSH & SSL .....	9-4
Network Security .....	9-7
Port Security.....	9-7
<b>10. Diagnostics .....</b>	<b>10-1</b>
System Status.....	10-2
Resource Utilization .....	10-2
Log & Event Notification .....	10-3
Event Log.....	10-3
Event Notification .....	10-4
Syslog .....	10-8
Email Notifications.....	10-9
Tools.....	10-10
Ping .....	10-10
<b>A. Account Privileges List .....</b>	<b>A-1</b>
User Role Privileges .....	A-1

## Introduction

---

Welcome to the Moxa NAT-102 Series industrial Network Address Translation device.

The following topics are covered in this chapter:

□ **Overview**

□ **Package Checklist**

□ **Features**

- Quick and User-friendly Access Control
- Industrial-grade and Ultra-compact Design

## Overview

The NAT-102 Series is an industrial NAT device that is designed to simplify the IP configuration of machines in existing network infrastructure in factory automation environments. The NAT-102 Series provides complete NAT functionality to adapt your machines to specific network scenarios without complicated, costly, and time-consuming configurations. These devices also protect the internal network from unauthorized access by outside hosts.

## Package Checklist

The NAT-102 Series is shipped with the following items. If any of these items are missing or damaged, please contact your customer service representative for assistance.

- 1 Industrial NAT device
- USB-C-to-DB9 cable
- Protective caps for unused ports
- Quick installation guide (printed)
- Warranty card

## Features

- User-friendly NAT functionality simplifies network integration
- Hands-free network access control through automatic whitelisting of locally connected devices
- Ultra-compact size and robust industrial design suitable for cabinet installation
- Integrated security features to ensure device and network safety
- Supports secure boot for checking system integrity
- -40 to 75°C operating temperature range (-T model)

## Quick and User-friendly Access Control

The NAT-102 Series' Auto Learning Lock feature automatically learns the IP and MAC address of locally connected devices and binds them to the access list. This feature not only helps you manage access control but also makes device replacements much more efficient.

## Industrial-grade and Ultra-compact Design

The NAT-102 Series' rugged hardware makes these NAT devices ideal for deployment in harsh industrial environments, featuring wide-temperature models that are built to operate reliably in hazardous conditions and extreme temperatures of -40 up to 75°C. Moreover, the ultra-compact size allows the NAT-102 Series to be easily installed into cabinets.

## Getting Started

---

This chapter explains how to access the Industrial NAT device for the first time. There are three ways to access the device: (1) serial console, (2) Telnet console, or (3) web browser. The serial console connection method, which requires using a serial cable to connect the Industrial NAT device to a PC's COM port, can be used if you do not know the Industrial NAT device's IP address. The Telnet console and web browser connection methods can be used to access the Industrial NAT device over an Ethernet LAN, or over the Internet. All monitoring and administration functions can be performed when accessing the device through a web browser. Accessing the device using the serial console and Telnet console only allow you to manage basic functions.

The following topics are covered in this chapter:

- ❑ **RS-232 Console Configuration (115200, None, 8, 1, VT100)**
- ❑ **Using Telnet to Access the Industrial NAT Device's Console**
- ❑ **Using a Web Browser to Configure the Industrial NAT Device**

# RS-232 Console Configuration (115200, None, 8, 1, VT100)



## ATTENTION

We strongly suggest that you do NOT use more than one connection method at the same time. Following this advice will allow you to maintain better control over the configuration of your Industrial NAT device.


## NOTE

We recommend using Moxa PComm Terminal Emulator, which can be downloaded free of charge from Moxa's website.


Before running the PComm Terminal Emulator, use a USB-C-to-DB9-F (or USB-C-to-DB25-F) cable to connect the Industrial NAT device's USB-C console port to your PC's COM port (generally COM1 or COM2, depending on how your system is set up).

After installing PComm Terminal Emulator, perform the following steps to access the RS-232 console utility.

1. From the Windows desktop, click **Start** → **Moxa** → **PComm Terminal Emulator**.




2. Click **Open** in the Port Manager menu to open a new connection.







3. The **Communication Parameter** page of the **Property** window will appear. Select the appropriate COM port from the **Serial Parameters** list, 115200 for Baud Rate, 8 for Data Bits, None for Parity, and 1 for Stop Bits.



4. Click the **Terminal** tab, select VT100 for Terminal Type, and then click **OK** to continue.
5. The **Console** login screen will appear. Enter the login account (**admin** or **user**) and press **Enter** to jump to the **Password** field. Enter the console password or if no password has been configured before, enter the default password "**moxa**" and press **Enter**.



6. Enter a question mark (?) to display the command list.



The following table lists commands that can be used when the Industrial NAT device is in console (serial or Telnet) mode:

### Admin Account Commands

Command	Description
quit	Exit Command Line Interface
exit	Exit Command Line Interface
reload	Halt and Perform a Cold Restart
terminal	Configure Terminal Page Length
copy	Import or Export File
config-file	Configure file
no	Negate a command or set its defaults
save	Save Running Configuration to Local Storage
ping	Send Echo Messages
clear	Clear Information
show	Show System Information
configure	Enter Configuration Mode
sslcertgen	Generate SSL certificate
sshkeygen	Generate SSH host key

## Using Telnet to Access the Industrial NAT Device's Console


You may use Telnet to access the Industrial NAT device's console utility over a network. To access the NAT device's functions over the network (by either Telnet or a web browser) from a PC host that is connected to the same LAN as the Industrial NAT device, you need to make sure that the PC host and the Industrial NAT device are on the same logical subnet. To do this, check your PC host's IP address and subnet mask. By default, the NAT-102's LAN IP address is 192.168.127.254 and the subnet mask is 255.255.255.0 (for a Class C subnet). If you have not changed these values, and your PC host's subnet mask is 255.255.0.0, then the PC's IP address should be 192.168.xxx.xxx. On the other hand, if your PC host's subnet mask is 255.255.255.0, then its IP address should be 192.168.127.xxx.

**NOTE** Before accessing the console utility via Telnet, first connect the Industrial NAT device's RJ45 Ethernet LAN port to your Ethernet LAN, or directly to your PC's Ethernet card (NIC). You can use either a straight-through or cross-over Ethernet cable.


**NOTE** The Industrial NAT device's default LAN IP address is 192.168.127.254.

Perform the following steps to access the console utility via Telnet.


1. Click **Start** → **Run**, and then telnet to the Industrial NAT device’s IP address from the Windows Run window. (You may also issue the Telnet command from the MS-DOS prompt.)



2. The **Console** login screen will appear. Enter the login account (**admin** or **user**) and press **Enter** to jump to the **Password** field. Enter the console password or if no password has been configured before, enter the default password "**moxa**" and press **Enter**.



3. Enter a question mark (?) to display the command list.



The following table lists commands that can be used when the Industrial NAT device is in console (serial or Telnet) mode:

### Admin Account Commands

Command	Description
quit	Exit Command Line Interface
exit	Exit Command Line Interface
reload	Halt and Perform a Cold Restart
terminal	Configure Terminal Page Length
copy	Import or Export File

config-file	Configure file
no	Negate a command or set its defaults
save	Save Running Configuration to Local Storage
ping	Send Echo Messages
clear	Clear Information
show	Show System Information
configure	Enter Configuration Mode
sslcertgen	Generate SSL certificate
sshkeygen	Generate SSH host key

## Using a Web Browser to Configure the Industrial NAT Device

The Industrial NAT device's web browser interface provides a convenient way to modify the NAT device's configuration settings and access the device's monitoring and network administration functions. The recommended web browser is Microsoft Internet Explorer 6.0 with JVM (Java Virtual Machine) installed.

**NOTE** To use the Industrial NAT device's management and monitoring functions from a PC host connected to the same LAN as the Industrial NAT device, you must make sure that the PC host and the Industrial NAT device are connected to the same logical subnet.

**NOTE** Before accessing the Industrial NAT device's web browser, first connect the Industrial NAT device's RJ45 Ethernet LAN port to your Ethernet LAN, or directly to your PC's Ethernet card (NIC). You can use either a straight-through or cross-over Ethernet cable.


**NOTE** The Industrial NAT device's default LAN IP address is 192.168.127.254.

Perform the following steps to access the Industrial NAT device's web browser interface.


1. Start Internet Explorer, type the Industrial NAT device's LAN IP address in the address field and press **Enter**.



2. The web login page will open. Enter the username (**Admin** or **User**) and password. If a password has not been set yet, enter the default password "moxa".



Use the menu tree on the left side of the screen to open the function pages to access each of the NAT's functions.

The image displays the web interface dashboard for a Moxa NAT-102-T device. The interface includes a top navigation bar with the Moxa logo and 'NAT-102-T' model name, and a user profile 'Hi, admin' with an 'Advanced' dropdown. A left sidebar contains a search bar and a menu tree with categories like 'Device Summary', 'Wizard', 'System', 'Network Configuration', 'Network Service', 'Routing & NAT', 'Firewall', 'Security', and 'Diagnostics'. The main content area is titled 'Device Summary' and contains several widgets: 'Model Information' (listing product model, name, LAN/WAN IP addresses, and MAC address), 'Panel Status' (showing 1 link up and 1 link down port), 'Event Summary' (showing 0 critical, error, warning, and notice events), 'CPU Usage History (%)' (a line graph showing usage over time), and 'Memory Usage History (%)' (a line graph showing memory usage over time).

## Device Summary and Wizard

---

This chapter describes how to access the Industrial NAT device's configuration options, perform monitoring, and use administration functions. There are three ways to access these functions: (1) RS-232 console, (2) Telnet console, and (3) web browser.

The web browser is the most user-friendly way to configure the Industrial NAT device, since you can both monitor the Industrial NAT device and use administration functions from the web browser. A serial or Telnet console connection only provides access to basic functions. In this chapter, we use the web browser to introduce the Industrial NAT device's configuration and monitoring functions.

The following topics are covered in this chapter:


- **Device Summary**

- **Wizard**


- Step 1: Welcome
- Step 2: Network Configuration
- Step 3: NAT Settings
- Step 4: Device Lockdown
- Step 5: Setup Complete!

# Device Summary


When logging in to the NAT-102, you will be presented with the Device Summary page. This overview page contains basic activity and performance information of the device.



Use the menu tree on the left side of the screen to open the different configuration pages of the NAT's functions.

Clicking  at the top-left side will close or expand the function menu.

Clicking  at the top-right side will expand the drop-down menu shown below.




### **Reboot**

Restart the device.

**Reset to Defaults**

This function will reset all settings to their factory default values. Be aware that all your configuration settings will be permanently deleted.

The **Reset to Defaults** option gives users a quick way of restoring the Industrial NAT device’s configuration settings to the factory default values. This function is available in both the console utility (serial or Telnet) and the web browser interface.



When prompted, select **Enable** from the drop-down menu to keep certificate database and configuration information, or select **Disabled** to reset everything to its their factory default value.

**Log Out**


Log out of the device.


**Model Information**

This panel shows basic information for the NAT device.


**Panel Status**

Clicking  will show the Panel View, representing the faceplate of the actual NAT device.



Click  to close the panel view of actual NAT device.

**Event Summary**

Click [View All Event Logs](#)  to jump to the Event Log page.

**CPU Usage History (%)**

This panel shows the device’s CPU usage. Click  to refresh the information.

**Memory Usage History**

This panel shows the device’s memory usage. Click  to refresh the information.




# Wizard

The NAT-102 Series supports a Setup Wizard to help you quickly configure basic device settings including IP and NAT settings.

Click **Wizard** in the function column to start the Setup Wizard.

## Step 1: Welcome


Click the **Next** to start the wizard.



## Step 2: Network Configuration

Configure the IP address of Port 1 (Internal Port) and Port 2 (External Port) and define the subnet of the LAN ports on the NAT device. The default LAN IP address is 192.168.127.254, and the default subnet address is 255.255.255.0.


For more detailed instructions, refer to [Network Configuration](#).



### Step 3: NAT Settings

Click **+** to configure add a NAT rule.


For more detailed instructions, refer to the NAT Settings section in [Routing & NAT](#).



### Step 4: Device Lockdown

Enable the device lockdown feature and select which interface you want to lock down, then click **NEXT**.


For more detailed instructions, refer to the Device Lockdown section in [Security](#).



## Step 5: Setup Complete!

Click **APPLY** to apply all settings and finish the process.

**NOTE** Any existing configurations will be overwritten by the new settings configured in the Setup Wizard.



The System section includes the most common settings required by administrators to maintain and control the device.

The following topics are covered in this chapter:

▣ **System Management**

- Device Information
- Firmware Upgrade
- Configuration Backup and Restore

▣ **Account Management**

- User Account
- Password Policy

▣ **Management Interface**

- User Interface

▣ **Time**

- System Time
- Time Zone

# System Management

## Device Information

The **Device Information** screen lets you edit information about the device to make it easier to identify the device on the network.

### Device Information

Device Name  
42674

---

6 / 30

Location  
Device Location

---

15 / 80

Description

---

0 / 40

Contact Information

---

0 / 40

APPLY

### Device Name

Setting	Description	Factory Default
Max. 30 characters	Enter a name for the device. This allows you to more easily identify the role or application of this unit. For example, "Factory NAT Device 1".	NAT device number

### Location

Setting	Description	Factory Default
Max. 80 characters	Enter a location for the device to quickly identify where the device is deployed.	Device Location


### Description


Setting	Description	Factory Default
Max. 40 characters	Enter a description for the device.	None

### Contact Information

Setting	Description	Factory Default
Max. 40 characters	Enter the contact information of the person responsible for the device.	None

## Firmware Upgrade

Click  to select a firmware file stored locally on the host computer. With the firmware selected, click **UPGRADE** to start the upgrade process. This procedure will take several minutes to complete.



The screenshot shows a web interface titled "Firmware Upgrade". At the top, there is a tab labeled "Local". Below the tab is a text input field with the placeholder text "Select File" and a file selection icon (a folder with a plus sign). Below the input field is a button labeled "UPGRADE".


## Configuration Backup and Restore

### Local

On large-scale networks, administrators need to configure many network devices. This is often a time-consuming and error-prone process. By using **Configuration Backup and Restore**, you can easily duplicate the system configuration of one NAT device to other NAT devices in a short period of time.

The system configuration, including firewall rules and certificates, only needs to be set up for one device and can then be backed up to a flash drive. You can then use this flash drive to quickly upload these configuration settings to other devices.

Click **BACK UP** button to back up the configuration settings, or click  to select a configuration backup file from the local host or flash drive and then click **RESTORE** to load the configuration file onto the device.



The screenshot shows a web interface titled "Configuration Backup and Restore". At the top, there are two tabs: "Local" (which is selected) and "File Encryption". Below the tabs is a button labeled "BACK UP". Below that is a text input field with the placeholder text "Select File" and a file selection icon. The input field contains the text "MOXA\_CFG.ini". Below the input field is a button labeled "RESTORE".

## File Encryption

To export the configuration as an encrypted text-based (command line type) configuration file, select the **Configuration File Signature** and **Signature Information** options and enter an encryption key string, then click **APPLY**. The key string is also used for decrypting when importing an encrypted configuration file.

### Configuration Backup and Restore

Local
File Encryption

Configuration File Signature ▼

Signature Information  
Encrypt sensitive information only ▼

Key String  
.... 4 / 31

APPLY

### Configuration File Signature

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the use of a digital signature for checking the configuration file integrity.	None

### Signature Information

Setting	Description	Factory Default
Encrypt sensitive information only	Only encrypt password-related sensitive information in the exported configuration.	Encrypt sensitive information only
Encrypt all information	Encrypt all information in the exported configuration.	

### Key String

Setting	Description	Factory Default
Max. 31 characters	Enter an encryption key string. This key string is also used to decrypt encrypted configuration files.	moxa

# Account Management

## User Account

The Moxa Industrial NAT device’s account management function allows you to create, manage, modify, and remove user accounts. There are three levels of configuration access, admin, supervisor, and user. The admin accounts have read/write access to all configuration parameters. Supervisors have full editing rights but cannot create, modify, or delete accounts. User-level accounts have read-only access and can only view configurations.

**NOTE**

1. We strongly recommend changing the default password after logging in for the first time.
2. The default 'admin' account cannot be deleted and is enabled by default.

### User Accounts

+
Search

	Status	Username	Authority
<input type="checkbox"/>	Enabled	admin	Admin
<input type="checkbox"/>	Enabled	configadmin	Supervisor
<input type="checkbox"/>	Enabled	user	User

Max 10
1 - 3 of 3

### Create New Account

Click **+** to create a new user account. Enter a username and password, assign the status and the authority to the new account, and click **CREATE**. Once created, the new account will appear in the Account List table.

#### Edit Account Settings

Status \* ▼

---

Username \*

At least 4 characters 0 / 31

---

Authority \* ▼

---

New Password \*

At least 4 characters 0 / 16

---

Confirm Password \*

At least 4 characters 0 / 16

---

CANCEL
CREATE



**Status**

Setting	Description	Factory Default
Enabled	The NAT device can be accessed by the enabled user.	None
Disabled	The NAT device cannot be accessed by the disabled user.	

**Username**

Setting	Description	Factory Default
4 to 31 characters	Enter a username for the user account.	None

**Authority**

Setting	Description	Factory Default
Admin	The account has read/write access to all configuration parameters.	None
Supervisor	The account has read/write access to all configuration parameters except create, delete, and modify accounts.	
User	The account can only view configurations but cannot make any modifications.	


**New Password**

Setting	Description	Factory Default
4 to 16 characters	Enter a password for the user account.	None

**Confirm Password**

Setting	Description	Factory Default
4 to 16 characters	Enter the password for the user account again.	None

**Modify Existing Account**

Select the existing account from the Account List table and click  to modify the account. When you are done modifying the account details, click **APPLY** to save your changes.

**Edit Account Settings**

Status

Username  
  
At least 4 characters 4 / 31

Authority \*


Old Password \*  
  
At least 4 characters 0 / 16

New Password \*  Confirm Password \*   
At least 4 characters 0 / 16 At least 4 characters 0 / 16


**Old Password**




Setting	Description	Factory Default
4 to 16 characters	If you want to change the account password, enter the current password of the user account.	None

**Delete Existing Account**

Select the existing account from the Account List table and click  to delete the account.

**User Accounts**


Search


	Status	Username	Authority
<input type="checkbox"/>	 Enabled	admin	Admin
<input type="checkbox"/>	 Enabled	configadmin	Supervisor
<input checked="" type="checkbox"/>	 Enabled	user	User



Max 10
1 - 3 of 3

**Search Existing Account**

Enter the username of the account in the Search field. Any user accounts matching the search criteria will be shown in the Account List table.

**User Accounts**


Search

	Status	Username	Authority
<input type="checkbox"/>	 Enabled	admin	Admin
<input type="checkbox"/>	 Enabled	configadmin	Supervisor

Max 10
1 - 2 of 2

## Password Policy

Using the password policy function, administrators can force more complex login passwords to improve the overall security of the system. At the same time, administrators can configure an account login failure lockout time to avoid unauthorized users from gaining access.

### Password Policy

Minimum Length \*

4 - 16

Password complexity strength check

Disabled ▼

Must contain at least one digit (0-9)

Disabled ▼

Must include both upper and lower case letters (A-Z, a-z)

Disabled ▼

Must contain at least one special character (~!@#\$%^&\*-\_;:.,<>{}|() )

Disabled ▼

### Minimum Length

Setting	Description	Factory Default
4 to 16 characters	Enter the minimum required password length.	4

### Password complexity strength check

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the password complexity strength check.	Disabled

### Must contain at least one digit (0-9)

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the requirement of the password to contain at least one digit.	Disabled

### Must include both upper and lower case letters (A-Z, a-z)

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the requirement of the password to include both upper- and lower-case letters.	Disabled

### Must contain at least one special character (~!@#\$%^&\*-\_;:.,<>{}|() )

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the requirement of the password to contain at least one special character.	Disabled

## Management Interface

From the Management Interface screen, you can manage from which interfaces the device can be accessed.

# User Interface

### User Interface

HTTP	TCP Port (HTTP) *	
Enabled <span style="float: right;">▼</span>	80	<hr style="border: 0; border-top: 1px solid #ccc; margin: 2px 0;"/>
	2 - 65535	
HTTPS	TCP Port (HTTPS) *	
Enabled <span style="float: right;">▼</span>	443	<hr style="border: 0; border-top: 1px solid #ccc; margin: 2px 0;"/>
	2 - 65535	
Telnet	TCP Port (Telnet) *	
Enabled <span style="float: right;">▼</span>	23	<hr style="border: 0; border-top: 1px solid #ccc; margin: 2px 0;"/>
	2 - 65535	
SSH	TCP Port (SSH) *	
Enabled <span style="float: right;">▼</span>	22	<hr style="border: 0; border-top: 1px solid #ccc; margin: 2px 0;"/>
	2 - 65535	
Ping Response (WAN)		
Disabled <span style="float: right;">▼</span>		
Moxa Service		
Disabled <span style="float: right;">▼</span>		
TCP Port for Moxa Service (Encrypted)		
	443	<hr style="border: 0; border-top: 1px solid #ccc; margin: 2px 0;"/>
UDP Port for Moxa Service (Encrypted)		
	40404	<hr style="border: 0; border-top: 1px solid #ccc; margin: 2px 0;"/>
Maximum Number of Login Sessions for HTTP+HTTPS *		
	5	<hr style="border: 0; border-top: 1px solid #ccc; margin: 2px 0;"/>
	1 - 10	
Maximum Number of Login Sessions for Telnet+SSH *		
	5	<hr style="border: 0; border-top: 1px solid #ccc; margin: 2px 0;"/>
	1 - 5	

APPLY

### HTTP

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable HTTP.	Enabled

### TCP Port (HTTP)

Setting	Description	Factory Default
2 to 65535	Enter the TCP port for HTTP.	80

### Enable HTTPS

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable HTTPS.	Enabled

### TCP Port (HTTPS)

Setting	Description	Factory Default
2 to 65535	Enter the TCP port for HTTPS.	443

### Enable Telnet

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable Telnet.	Enabled

### TCP Port (Telnet)

Setting	Description	Factory Default
2 to 65535	Enter the TCP port for Telnet.	23

**Enable SSH**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable SSH.	Enabled

**TCP Port (SSH)**

Setting	Description	Factory Default
2 to 65535	Enter the TCP port for SSH.	22

**Ping Response (WAN)**

Setting	Description	Factory Default
Enabled/Disabled	If a WAN connection has been established, enable this feature to have the WAN port respond to ping requests.	Disabled

**NOTE** To successfully ping the WAN port, make sure "Ping Response (WAN)" is enabled, and the ping sender IP is in the "Trusted Access" list, or "Accept All LAN Port Connection" in Trusted Access is enabled.

**MOXA Service**

Setting	Description	Factory Default
Enabled/Disabled	This option will be supported in a future firmware version.	Disabled

**TCP Port for Moxa Service (Encrypted)**

Setting	Description	Factory Default
2 to 65535	This option will be supported in a future firmware version.	443

**UDP Port for Moxa Service (Encrypted)**

Setting	Description	Factory Default
2 to 65535	This option will be supported in a future firmware version.	40404

**Maximum Number of Login Sessions for HTTP+HTTPS**

Setting	Description	Factory Default
1 to 10	Specify the maximum combined number of users that can be logged in to the NAT device using HTTP and HTTPS. The maximum number of users is 10.	5

**Maximum Number of Login Sessions for Telnet+SSH**

Setting	Description	Factory Default
1 to 5	Specify the maximum combined number of users that can be logged in to the NAT device using Telnet and SSH. The maximum number of users is 5.	5

# Time

## System Time

The Moxa Industrial NAT device's system time can be synced with an NTP server or can be user-specified. The system time is also used for time stamps in functions such as automatic warning emails.

**NOTE** The Moxa Industrial NAT device does not feature a real-time clock. If there is no NTP server on the network or the device is not connected to the Internet, the Current Time and Current Date must be manually reconfigured after each reboot.

## Time

### System Time

Time
NTP Server

Current Time  
Fri Oct 29 2021 17:24:09 UTC+08:00

---

Clock Source  
Local

Date \*  
10/29/2021

Time  
05:24 PM

APPLY
Sync With Browser
Refresh

### Current Time

This shows the current date, time, and time zone.

**NOTE** Click **Sync With Browser** to synchronize the device's clock with the browser time. Click **Refresh** to update all the information on the page.

### Clock Source

Setting	Description	Factory Default
Local	Set the clock source to local time. This will require you to manually specify the time and date.	Local
SNTP	Set the clock source to SNTP.	
NTP	Set the clock source to NTP.	

### Time Server

Setting	Description	Factory Default
Time server 1/2	If SNTP or NTP is selected as the clock source, specify the time server	None

### Date

Setting	Description	Factory Default
Date	Set the date manually.	Current date DD/MM/YYYY

**Time**

Setting	Description	Factory Default
Time	Set the time manually.	Current time HH:MM AM/PM

**NTP Server**

### System Time

Time

NTP Server

NTP Server  
Disabled ▼

APPLY

**NTP Server**

Setting	Description	Factory Default
Enabled/Disabled	Enables NTP server functionality for clients.	Disabled

**Time Zone**

### Time Zone

System Uptime  
0d1h1m43s

---

Current Time  
Fri Oct 29 2021 17:25:14 UTC+08:00

---

Time Zone  
(UTC+08:00) Taipei ▼

**Daylight Saving**

Status  
Disabled ▼

**Start**

Month Week Day Hour Minutes

--- ▼ --- ▼ --- ▼ --- ▼ --- ▼

---

**End**

Month Week Day Hour Minutes

--- ▼ --- ▼ --- ▼ --- ▼ --- ▼

---

**Offset**

Offset (Hour)  
0 ▼

APPLY

**System Uptime**

Indicates how long the Moxa NAT device has been online for since the last cold start.

**Current Time**

Indicates the current date and time.

**Time Zone**

Setting	Description	Factory Default
Time zone	Specify the time zone, which is used to determine the local time offset from UTC.	UTC

**Daylight Saving**

The Daylight Saving time settings are used to automatically set the device's time forward according to national standards.

**Status**

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable Daylight Saving time.	Disabled

**Start****Month**

Setting	Description	Factory Default
User-specified month	Specify the month the Daylight Saving time begins.	None

**Week**

Setting	Description	Factory Default
User-specified week	Specify the week the Daylight Saving time begins.	None

**Day**

Setting	Description	Factory Default
User-specified day	Specify the day the Daylight Saving time begins.	None

**Hour**

Setting	Description	Factory Default
User-specified hour	Specify the hour the Daylight Saving time begins.	None

**Minutes**

Setting	Description	Factory Default
User-specified minutes	Specify the minutes the Daylight Saving time begins.	None

**End****Month**

Setting	Description	Factory Default
User-specified month	Specify the month the Daylight Saving time ends.	None

**Week**

Setting	Description	Factory Default
User-specified week	Specify the week the Daylight Saving time ends.	None

**Day**

Setting	Description	Factory Default
User-specified day	Specify the day the Daylight Saving time ends.	None

**Hour**

Setting	Description	Factory Default
User-specified hour	Specify the hour the Daylight Saving time ends.	None



**Minutes**

Setting	Description	Factory Default
User-specified minutes	Specify the minutes the Daylight Saving time ends.	None

**Offset****Offset (Hour)**

Setting	Description	Factory Default
User-specified hour	Specify the number of hours that the time should be set forward during Daylight Saving time.	0

**NOTE** Changing the time zone will automatically correct the current time. Be sure to select the time zone before setting the time.

# 5

## Network Configuration

---

The following topics are covered in this chapter:

□ **Port**

- Port Settings

□ **Layer 2 Switching**

- VLAN
- MAC Address Table

□ **Layer 3 Interfaces**

# Port

## Port Settings

Port settings let you manage port access, port transmission speed, flow control, and port type (MDI or MDIX). The NAT-102 Series has two RJ45 Ethernet ports.

### Setting

### Port Settings

Setting
Status

Port	Status	Media Type	Description	Speed/Duplex	Flow Control	MDI/MDIX
1	Enabled	100TX,RJ45		Auto	Disabled	Auto
2	Enabled	100TX,RJ45		Auto	Disabled	Auto

1 - 2 of 2

### Modify Port Settings

Click to modify the settings of the corresponding port.

#### Edit Port 1 Settings

Status  
Enabled ▼

Media Type  
100TX,RJ45

Description  
\_\_\_\_\_ 0 / 127

Speed/Duplex Mode  
Auto ▼

Flow Control  
Disabled ▼

MDI/MDIX  
Auto ▼

CANCEL
APPLY

#### Status

Setting	Description	Factory Default
Enabled	Allows data transmission through the port.	Enabled
Disabled	Disables the port.	

**Media Type**

Setting	Description	Factory Default
Media type	Displays the port's media type.	Current media type

**Description**

Setting	Description	Factory Default
Max. 127 characters	Specifies an alias for the port to help administrators differentiate between different ports. Example: PLC 1	None

**Speed**

Setting	Description	Factory Default
Auto	Allows the port to use the IEEE 802.3u protocol to negotiate the port speed and duplex mode with the connected device. The port and connected devices will determine the best speed for that connection.	Auto
100M-Full	Select a fixed speed and duplex mode if the connected Ethernet device has trouble auto-negotiating the line speed.	
100M-Half		
10M-Full		
10M-Half		

**Flow Control**

This setting allows you to enable or disable the flow control feature for the port when the port's Speed is set to Auto. Flow control helps manage the data transfer rate between the NAT-102 and the connected Ethernet device.

Setting	Description	Factory Default
Enable	Enables flow control for this port when the port's Speed is set to Auto.	Disabled
Disable	Disables flow control.	

**MDI/MDIX**

Setting	Description	Factory Default
Auto	Allows the port to auto-detect the port type of the connected Ethernet device and change the port type accordingly.	Auto
MDI	Choose MDI or MDIX if the connected Ethernet device has trouble auto-negotiating for port type.	
MDIX		

**Status**

The Status page shows the current status of the Ethernet ports including the port transmission speed, flow control, and port type (MDI or MDIX).

### Port Settings

Setting
Status

↻
Q Search

Media Type	Link Status	Flow Control	MDI/MDIX
100TX,RJ45	100M-Full	Off	MDI
100TX,RJ45	-	-	-

1 - 2 of 2

# Layer 2 Switching

## VLAN

The VLAN section is used for configuring VLAN functionality for the NAT-102's ports.

### Using Virtual LAN


Setting up Virtual LANs (VLANs) on your Moxa Industrial NAT device increases the efficiency of your network by dividing the LAN into logical segments, as opposed to physical segments. In general, VLANs are easier to manage.

### The VLAN Concept

#### What is a VLAN?

A VLAN is a group of devices that can be located anywhere on a network, but which communicate as if they are on the same physical segment. With VLANs, you can segment your network without being restricted by physical connections—a limitation of traditional network design. With VLANs you can segment your network into:

- **Departmental groups**—you could have one VLAN for the marketing department, another for the finance department, and another for the product development department.
- **Hierarchical groups**—you could have one VLAN for directors, another for managers, and another for general staff.
- **Usage groups**—you could have one VLAN for email users and another for multimedia users.



#### Benefits of VLANs

The main benefit of VLANs is that they provide a network segmentation system that is far more flexible than traditional networks. Using VLANs also provides you with three other benefits:

- **VLANs ease the relocation of devices on networks:** With traditional networks, network administrators spend much of their time dealing with moves and changes. If users move to a different sub-network, the addresses of each host must be updated manually. With a VLAN setup, if a host originally on VLAN Marketing, for example, is moved to a port on another part of the network, and retains its original subnet membership, you only need to specify that the new port is on VLAN Marketing. You do not need to do any re-cabling.
- **VLANs provide extra security:** Devices within each VLAN can only communicate with other devices on the same VLAN. If a device on VLAN Marketing needs to communicate with devices on VLAN Finance, the traffic must pass through a routing device or Layer 3 switch.

- **VLANs help control traffic:** With traditional networks, congestion can be caused by broadcast traffic that is directed to all network devices, regardless of whether or not they need it. VLANs increase the efficiency of your network because each VLAN can be set up to contain only those devices that need to communicate with each other.


**Managing a VLAN**

A new or initialized Moxa Industrial NAT device contains a single VLAN—the Default VLAN. This VLAN has the following definition:

- **VLAN Name**—Management VLAN
- **Management Port**—1 (if tagging is required)

All of the ports are initially placed on this VLAN, and it is the only VLAN that allows you to access the management software of the NAT device over the network.

**Global**



**Management VLAN**

**Management VLAN**

Setting	Description	Factory Default
1, 2	Select the VLAN ID of this Moxa NAT device.	1

**Management Port Quick Settings**

Use this for quick and easy configuration of VLAN settings for multiple ports at once.

**Management Port**

Setting	Description	Factory Default
1, 2	Select the management port of this Moxa NAT device. Set the Mode, PVID, Tagged VLAN ID, and Untagged VLAN ID and click <b>APPLY</b> button to create the VLAN ID configuration table.	None

## VLAN

Global
Settings
Switchport Table

**Management VLAN**

Management VLAN

**Management Port Quick Settings**

Management Port  
 i

Mode

PVID

Tagged VLAN

Untagged VLAN

APPLY

**Mode**

Setting	Description	Factory Default
Access	Select the Access port type to connect single devices without tags.	Access
Trunk	Select the Trunk port type to connect another 802.1Q VLAN aware NAT device.	
Hybrid	Select Hybrid port to connect another Access 802.1Q VLAN aware NAT device or another LAN that combines tagged and/or untagged devices and/or other NAT devices/hubs.	

**PVID**

Setting	Description	Factory Default
1, 2	Set the default VLAN ID for untagged devices that connect to the port.	1

**Tagged VLAN**

Setting	Description	Factory Default
All Member VIDs, 1, 2	If the Mode is set to Trunk or Hybrid, set the other VLAN ID for tagged devices that connect to the port. Use commas to separate different VIDs.	1

**Untagged VLAN**

Setting	Description	Factory Default
All Member VIDs, 1, 2	If the Mode is set to Trunk or Hybrid, set the other VLAN ID for tagged devices that connect to the port and tags that need to be removed in egress packets. Use commas to separate different VIDs.	None

## Settings

### VLAN

Global
Settings
Switchport Table

+
Search

	VLAN	Member Port
<input type="checkbox"/>	1	1, 2

Max 10
1 - 1 of 1

---

↻
Search

	Port	Mode	PVID	Untagged VLAN	Tagged VLAN
	1	Access	1	1,	
	2	Access	1	1,	

1 - 2 of 2

### Create a VLAN

Click + to create a VLAN.

#### Create VLAN

VID \* i

Required


CANCEL
CREATE

### VID

Setting	Description	Factory Default
VLAN ID	Enter the VLAN ID. You can create multiple VLANs at once by entering single VLAN IDs or a range of IDs. For example, 2, 4-8, 10-13.	None



### Modify an Existing VLAN

Click  to modify the settings of the corresponding VLAN entry.

**Edit Port 1 Settings**

Mode  
Access

---

PVID  
1

---

Tagged VLAN

---

Untagged VLAN  
1

---

CANCEL APPLY

#### Mode

Setting	Description	Factory Default
Access	Select the Access port type to connect single devices without tags.	Access
Trunk	Select the Trunk port type to connect another 802.1Q VLAN aware NAT device.	
Hybrid	Select Hybrid port to connect another Access 802.1Q VLAN aware NAT device or another LAN that combines tagged and/or untagged devices and/or other NAT devices/hubs.	

#### PVID

Setting	Description	Factory Default
1, 2	Set the default VLAN ID for untagged devices that connect to the port.	1


#### Tagged VLAN


Setting	Description	Factory Default
All Member VLANs, 1, 2	If the Mode is set to Trunk or Hybrid, set the other VLAN ID for tagged devices that connect to the port. Use commas to separate different VLANs.	1

#### Untagged VLAN

Setting	Description	Factory Default
All Member VLANs, 1, 2	If the Mode is set to Trunk or Hybrid, set the other VLAN ID for tagged devices that connect to the port and tags that need to be removed in egress packets. Use commas to separate different VLANs.	None

### Delete a VLAN


Select the VLAN from the list and click  to delete it.



The screenshot shows the 'Switchport Table' configuration page. At the top, there are tabs for 'Global', 'Settings', and 'Switchport Table'. Below the tabs is a table with a trash icon at the top left and a search bar at the top right. The table has two columns: 'VLAN' and 'Member Port'. The first row shows VLAN 1 with member ports 1,2. The second row shows VLAN 2 with member ports 1,2, and this row is highlighted in light blue. At the bottom left, it says 'Max 10' and at the bottom right, it says '1 - 2 of 2'.

### Switchport Table

From the **VLAN Switchport Mode Table**, you can review created VLAN groups, joined Access, Trunk and Hybrid ports.



The screenshot shows the 'VLAN Switchport Mode Table' configuration page. At the top, there are tabs for 'Global', 'Settings', and 'Switchport Table'. Below the tabs is a section titled 'VLAN Switchport Mode Table' with a refresh icon at the top left and a search bar at the top right. The table has four columns: 'VLAN', 'Hybrid Port', 'Trunk Port', and 'Access Port'. The first row shows VLAN \*1 with Hybrid Port 1,2 and Access Port 1,2. The second row shows VLAN 2 with Hybrid Port 1,2 and Access Port 1,2, and this row is highlighted in light blue. At the bottom right, it says '1 - 2 of 2'.

## MAC Address Table

The MAC address table shows the MAC address list of devices that have passed through the Moxa Industrial NAT device. The Aging Time indicates how long the MAC address remains stored in the device before it is removed from the list. Once a MAC address is removed, the NAT device will no longer forward frames originating from this MAC address.

### MAC Address Table

Aging Time  
300  
10 - 300 sec

**APPLY**

↻
🔍 Search

Index	VLAN	MAC Address	Type	Port
1	1	cc:32:e5:d6:a9:ec	Learnt Unicast	1
2	1	b4:2e:99:1b:f8:85	Learnt Unicast	1
3	1	00:90:e8:97:72:64	Learnt Unicast	1

Max 2048
Items per page: 50
1 - 3 of 3
⏪ ⏩

You can quickly filter MAC addresses by entering one of the following criteria into the Search field.

<b>Learnt Unicast</b>	Show all learnt Unicast MAC addresses.
<b>Static</b>	Show all Static, Static Lock, and Static Multicast MAC addresses.
<b>Multicast</b>	Show all Static Multicast MAC addresses.
<b>Port x</b>	Show all MAC addresses associated with a specific port.

The table displays the following information:

<b>VLAN</b>	This field shows the VLAN ID.
<b>MAC Address</b>	This field shows the MAC address.
<b>Type</b>	This field shows the type of this MAC address.
<b>Port</b>	This field shows the port that this MAC address belongs to.

# Layer 3 Interfaces

## LAN

### Layer 3 Interfaces

LAN
WAN
Secondary IP

**+**
Search

	Name	Status	VLAN ID	Alias	IP Address	Netmask	Virtual MAC
<input type="checkbox"/>	LAN	Enabled	1		192.168.127.254	255.255.255.0	--

Max 2
Items per page: 50
1 - 1 of 1

### Create a LAN Interface

Click **+** to create a LAN Interface.

Enter the name of the LAN interface, set VLAN Interface to Enabled, select a VLAN ID that is already configured in the Layer 2 VLAN settings, and assign an Alias, IP address, Netmask, and Virtual MAC Address for the interface. Click **CREATE** to activate this interface.

#### Create LAN Interface Entry

**Name \***

Required

VLAN Interface \*

Enabled ▼

**VLAN ID \***

1 - 4093

Alias 0 / 31

**IP Address \***

24 (255.255.255.0) ▼

**Netmask \***

Virtual MAC

00:00:00:00:00:00

CANCEL
CREATE

#### Name

Setting	Description	Factory Default
Max. 12 characters	Enter a name for the interface.	None

#### VLAN Interface

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the VLAN interface.	Enabled

**VLAN ID**

Setting	Description	Factory Default
1 to 4093	Enter the VLAN ID.	None

**Alias**

Setting	Description	Factory Default
Max. 31 characters	Enter an alias for the VLAN interface.	None

**IP Address**

Setting	Description	Factory Default
IP address	Specify the IP address of the interface.	None

**Netmask**

Setting	Description	Factory Default
Subnet mask	Specify the subnet mask of the interface.	24 (255.255.255.0)

**Virtual MAC**

Setting	Description	Factory Default
Virtual MAC	Enter the virtual MAC address of the interface.	00:00:00:00:00:00

**Delete a LAN Interface**

Select the entry from the LAN Interface List and click  to delete it.

**Modify a LAN Interface**

Click  to modify the attributes and click **APPLY** button to change the configuration.

**NOTE** You can create up to 10 LAN interfaces by configuring each port with unique VLAN ID numbers.

## WAN

### Layer 3 Interfaces

LAN
WAN
Secondary IP

**VLAN ID**

VLAN ID  
-----

---

**Connection**

Status: Enabled  
Connection Type: Dynamic IP

**PPTP Dialup**

Status: Disabled

IP Address: 0.0.0.0    Username: \_\_\_\_\_    Password: \_\_\_\_\_

MPPE Encryption: None

**Virtual MAC**

Virtual MAC: 00:00:00:00:00:00

**DNS Settings**

Primary DNS Server: 0.0.0.0    Secondary DNS Server: 0.0.0.0    Tertiary DNS Server: 0.0.0.0

APPLY

### VLAN ID

#### VLAN ID

The Moxa Industrial NAT device’s WAN interface is VLAN-based. All ports associated with the selected VLAN ID will act as a single WAN interface.

Setting	Description	Factory Default
VLAN ID	Select a VLAN ID. The Moxa Industrial NAT device’s WAN interface is VLAN-based. All ports associated with the selected VLAN ID will act as a single WAN interface.	None

### Connection

#### Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the WAN interface.	Disabled

#### Connection Type

Setting	Description	Factory Default
Static IP	Choose the connection type. For more details and configuration settings for each type, refer to <a href="#">Dynamic IP</a> , <a href="#">Static IP</a> , and <a href="#">PPPoE</a> .	Dynamic IP
Dynamic IP		
PPPoE		

## Dynamic IP Connections

### Layer 3 Interfaces

LAN
WAN
Secondary IP

**VLAN ID**

VLAN ID  
-----

---

**Connection**

Status: Enabled  
Connection Type: Dynamic IP

**PPTP Dialup**

Status: Disabled

IP Address: 0.0.0.0    Username: \_\_\_\_\_    Password: \_\_\_\_\_

MPPE Encryption: None

**Virtual MAC**

Virtual MAC: 00:00:00:00:00:00

**DNS Settings**

Primary DNS Server: 0.0.0.0    Secondary DNS Server: 0.0.0.0    Tertiary DNS Server: 0.0.0.0

APPLY

### PPTP Dialup

The Point-to-Point Tunneling Protocol is used for Virtual Private Networks (VPN). Remote users can use PPTP to connect to private networks from public networks.

#### Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the PPTP connection.	Disabled

#### IP Address

Setting	Description	Factory Default
IP Address	The PPTP service IP address.	0.0.0.0

#### Username

Setting	Description	Factory Default
Max. 30 Characters	The username used to dial in to the PPTP service.	None

#### Password


Setting	Description	Factory Default
Max. 30 characters	The password used to dial in to the PPTP service.	None

#### MPPE Encryption

Setting	Description	Factory Default
None/Encrypt	Enable or disable the MPPE encryption.	None

**Example**

Suppose a remote user (IP: 10.10.10.10) wants to connect to the internal server (private IP: 30.30.30.10) via the PPTP protocol. The IP address for the PPTP server is 20.20.20.1. The necessary configuration settings are shown in the following figure.



**Virtual MAC**

*Virtual MAC*

Setting	Description	Factory Default
Virtual MAC Address	The virtual MAC address.	None

**DNS Settings**

*Primary DNS Server*

Setting	Description	Factory Default
IP Address	The primary DNS IP address.	0.0.0.0

*Secondary DNS Server*

Setting	Description	Factory Default
IP Address	The secondary DNS IP address.	0.0.0.0

*Tertiary DNS Server*

Setting	Description	Factory Default
IP Address	The tertiary DNS IP address.	0.0.0.0

**NOTE** The priority of a manually configured DNS will be higher than the DNS from the PPPoE or DHCP server.



## Static IP Connections

### Layer 3 Interfaces

LAN

WAN

Secondary IP

**VLAN ID**

VLAN ID  
2

---

**Connection**

Status: Enabled

Connection Type: Static IP

---

**Address Information**

IP Address: 0.0.0.0      Netmask \*:   
 Gateway: 0.0.0.0

---

**PPTP Dialup**

Status: Disabled

IP Address: 0.0.0.0      Username:      Password:

MPPE Encryption: None

---

**Virtual MAC**

Virtual MAC: 00:00:00:00:00:00

---

**DNS Settings**

Primary DNS Server: 0.0.0.0      Secondary DNS Server: 0.0.0.0      Tertiary DNS Server: 0.0.0.0

---

**APPLY**

### Address Information

#### IP Address

Setting	Description	Factory Default
IP Address	The interface IP address.	0.0.0.0

#### Netmask

Setting	Description	Factory Default
IP Address	The subnet mask.	None

#### Gateway

Setting	Description	Factory Default
IP Address	The gateway IP address.	0.0.0.0

## PPPoE Connections

### Layer 3 Interfaces

LAN

WAN

Secondary IP

**VLAN ID**

VLAN ID  
2

**Connection**

Status  
Enabled

Connection Type  
PPPoE

**PPPoE Dialup**

Username \* Password \* Host Name

**Virtual MAC**

Virtual MAC  
00:00:00:00:00:00

**DNS Settings**

Primary DNS Server Secondary DNS Server Tertiary DNS Server  
0.0.0.0 0.0.0.0 0.0.0.0

**APPLY**

### PPPoE Dialup

#### *Username*

Setting	Description	Factory Default
Max. 30 characters	The username used to log into the PPPoE server.	None

#### *Password*


Setting	Description	Factory Default
Max. 30 characters	The password used to log into the PPPoE server.	None

#### *Host Name*

Setting	Description	Factory Default
Max. 30 characters	The user-defined host name of the PPPoE server.	None

## Secondary IP

The Layer 3 interface can also act as a secondary IP, as in the example below, if the user needs to expand more IP addresses in the LAN segment and does not want to change the settings of the original interface IP/device, the new secondary IP can be used to create a new network segment.



### Layer 3 Interfaces

LAN	WAN	Secondary IP			
+ Search					
<input type="checkbox"/>	Interface	VLAN ID	IP Address	Netmask	Type
Max 256		Items per page: 50		0 of 0	

### Create a Secondary IP

Click **+** to create a secondary IP.

Select the interface and assign an IP address and subnet mask for the interface. Click **CREATE** to activate this interface.

**Create Secondary IP Entry**


Interface \* ▼

---

IP Address \* Netmask \* ▼

CANCEL CREATE

### Delete a Secondary IP


Select the interface from the Secondary IP List and click  to delete it.


#### Layer 3 Interfaces

LAN

WAN

Secondary IP


🔍 Search

<input checked="" type="checkbox"/>	Interface	VLAN ID	IP Address	Netmask	Type
<input checked="" type="checkbox"/> 	LAN	1	192.168.127.11	255.255.255.240	Manual

Max 256
Items per page: 50
1 - 1 of 1

### Modify a Secondary IP

Click  to modify the attributes and click **APPLY** to change the configuration.

# 6

## Network Service

---

The following topics are covered in this chapter:

□ **DHCP Server**

- General
- DHCP
- MAC-based IP Assignment
- Port-based IP Assignment
- Lease Table

# DHCP Server

## General

### DHCP Server

General
DHCP
MAC-based IP Assignment
Port-based IP Assignment
Lease Table

Mode

Disabled ▼

APPLY

### Mode

Setting	Description	Factory Default
Disabled, DHCP/MAC-based assignment, Port-based IP assignment	Select the DHCP Server Mode.	Disabled

## DHCP

The Industrial NAT device provides a DHCP (Dynamic Host Configuration Protocol) server function for LAN interfaces. When configured, the Industrial NAT device will automatically assign an IP address to an Ethernet device from a defined IP range.

### DHCP Server

General
DHCP
MAC-based IP Assignment
Port-based IP Assignment
Lease Table

+
Search

	Status	Pool IP Range	Subnet Mask	Lease Time (min)	Default Gateway	DNS Server 1	DNS Server 2	NTP Server
✎ 🗑	Disabled	192.168.127.10 - 192.168.127.100	255.255.255.254	1440	0.0.0.0	0.0.0.0	0.0.0.0	0.0.0.0

Max 10
1 - 1 of 1 < >

### Create a DHCP Server Pool

Click + to create a new DHCP Server Pool.

### Create DHCP Server Pool

Status ▼

Starting IP Address \*      Subnet Mask \* ▼

Ending IP Address \*

Default Gateway

Lease Time \*  
 1440  
5 - 99999 min

DNS Server 1      DNS Server 2

NTP Server

CANCEL
CREATE

**Status**

Setting	Description	Factory Default
Enable/Disable	Enable or disable the DHCP server pool.	None

**Starting IP Address**

Setting	Description	Factory Default
IP Address	The starting IP address of the DHCP IP range.	None

**Subnet Mask**

Setting	Description	Factory Default
Subnet Mask	The subnet mask for DHCP clients.	None

**Ending IP Address**

Setting	Description	Factory Default
IP Address	The ending IP address of the DHCP IP range.	None

**Default Gateway**

Setting	Description	Factory Default
IP Address	The default gateway for DHCP clients.	None

**Lease Time**

Setting	Description	Factory Default
5 to 99999 minutes	The lease time of the DHCP server.	1440

**DNS Server 1**

Setting	Description	Factory Default
IP Address	The first DNS server for DHCP clients.	None

**DNS Server 2**

Setting	Description	Factory Default
IP Address	The second DNS server for DHCP clients.	None

**NTP Server**

Setting	Description	Factory Default
IP Address	The NTP server for DHCP clients.	None

**NOTE**

1. The DHCP Server is only available for LAN interfaces.
2. The starting and ending IP addresses of the DHCP IP pool must be in the same logical subnet.

**Delete a DHCP Pool**

Click  next to the DHCP pool entry to delete it.

**Modify a DHCP Pool**

Click  to modify the attributes and click **APPLY** to change the configuration.

## MAC-based IP Assignment

Use the MAC-based IP list to ensure that devices connected to the Industrial NAT device always use the same IP address. The MAC-based IP list matches IP addresses to MAC addresses.

**DHCP Server**

General


DHCP

MAC-based IP Assignment

Port-based IP Assignment

Lease Table

+


<input type="checkbox"/>	Status	Hostname	IP Address	Subnet Mask	MAC Address	Lease Time (min)	Default Gateway	DNS Server 1	DNS Server 2	NTP Server
<input type="checkbox"/> 	Enabled	Device-01	192.168.127.101	255.255.255.0	00:09:ad:00:aa:01	1440	192.168.127.254	192.168.127.201	192.168.127.202	192.168.127.203

Max 256
Items per page: 50
1 - 1 of 1

In the above example, a Hostname "Device-01" was added to the list, with a MAC-based IP address set to 192.168.127.101 and MAC address set to 00:09:ad:00:aa:01. When a device with a MAC address of 00:09:ad:00:aa:01 is connected to the Industrial NAT device, the Industrial NAT device will assign the IP address 192.168.127.101 to this device.



### Create a MAC-based IP Entry

Click  to create a new MAC-based IP list. The hostname, IP address, and MAC address must be different from any existing MAC-based IP entries.

**Create Entry**

Status ▼

Hostname \* i  
0 / 63

IP Address \*      Subnet Mask \* ▼

MAC Address \*

Default Gateway

Lease Time \*  
 1440  
5 - 99999 min

DNS Server 1      DNS Server 2

NTP Server

CANCEL
CREATE

**Status**

Setting	Description	Factory Default
Enable/Disable	Enable or disable the MAC-based IP server function.	None

**Hostname**

Setting	Description	Factory Default
Max. 63 characters	The name of the device.	None

**IP Address**

Setting	Description	Factory Default
IP Address	The IP address of the device.	None

**Subnet Mask**

Setting	Description	Factory Default
Subnet Mask	The subnet mask of the device.	None

**MAC Address**

Setting	Description	Factory Default
MAC Address	The MAC address of the device.	None

**Default Gateway**

Setting	Description	Factory Default
IP Address	The default gateway of the device.	None

**Lease Time**

Setting	Description	Factory Default

5-99999 minutes	The lease time of the device.	1440
-----------------	-------------------------------	------

**DNS Server 1**

Setting	Description	Factory Default
IP Address	The first DNS server for the device.	None


**DNS Server 2**

Setting	Description	Factory Default
IP Address	The second DNS server for the device.	None

**NTP Server**

Setting	Description	Factory Default
IP Address	The NTP server for the device.	None

**Delete a MAC-based IP Entry**

Select the entry from the list and click  to delete it.

**Modify a MAC-based IP Entry**


Click  to modify the attributes and click **APPLY** button to change the configuration.

## Port-based IP Assignment

**DHCP Server**

General    DHCP    MAC-based IP Assignment    **Port-based IP Assignment**    Lease Table

---


Search

	Port	Status	IP Address	Subnet Mask	Lease Time (min)	Default Gateway	DNS Server 1	DNS Server 2	NTP Server
Max 2									

0 of 0

**Create a Port-based IP Entry**

Click  to create Port-based IP list.

**Create Entry**

Status ▼

---

Port \* ▼

---

IP Address \* Subnet Mask \* ▼

---

Default Gateway

---

Lease Time \*  
1440  
5 - 99999 min

---

DNS Server 1 DNS Server 2

---

NTP Server

---

CANCEL
CREATE

**Status**

Setting	Description	Factory Default
Enable/Disable	Enable or disable the Port-based IP function.	None

**Port**

Setting	Description	Factory Default
Port	Select the physical port on the device to associate the IP with.	None

**IP Address**

Setting	Description	Factory Default
IP Address	The IP address of the connected device.	None

**Subnet Mask**

Setting	Description	Factory Default
Subnet Mask	The subnet mask for the connected device.	None

**Default Gateway**

Setting	Description	Factory Default
IP Address	The default gateway for the connected device.	None

**Lease Time**

Setting	Description	Factory Default
5-99999 minutes	The lease time of the connected device.	1440

**DNS Server 1**

Setting	Description	Factory Default
IP Address	The first DNS server for the connected device.	None


**DNS Server 2**

Setting	Description	Factory Default
IP Address	The second DNS server for the connected device.	None


**NTP Server**

Setting	Description	Factory Default
IP Address	The NTP server for the connected device.	None

**Delete a Port-based IP Entry**

Select the entry from the list and click  to delete it.

**Modify a Port-based IP Entry**


Click  to modify the attributes and click **APPLY** to change the configuration.

## Lease Table

The Lease Table provides an overview of the current DHCP clients.

### DHCP Server

- General
- DHCP
- MAC-based IP Assignment
- Port-based IP Assignment
- Lease Table**



Hostname	IP Address	MAC Address	Time Left
----------	------------	-------------	-----------

Items per page: 50 0 of 0 |< < > >|

The following topics are covered in this chapter:

▣ **Unicast Routing**

- Static Routes
- Routing Table

▣ **NAT Settings**

- NAT Concept
- 1-to-1 NAT Overview
- 1-to-1 NAT
- N-to-1 NAT
- PAT
- Advance

# Unicast Routing


The Industrial NAT device supports static routing. A routing entry includes the following items: the destination address, the next hop address (which is the next router along the path to the destination address), and a metric that represents the cost to access a different network.

## Static Route

You can define static routes by specifying the next hop (or router) that the Industrial NAT device forwards data to within a specific subnet. The settings of the Static Route will be added to the routing table and stored on the Industrial NAT device.

## Static Routes

The Static Routes page is used to configure the Industrial NAT device’s static routing table.



### Create a Static Route

Click **+** to create new static route. Click **CREATE** to add the entry to the Static Routing Table.

**Create New Static Route**

Status \* ▼

---

Name \* 0 / 10

---

Destination Address \*

---

Netmask \*

---

Next Hop \*

---

Metric \* 1 - 255

---

CANCEL
CREATE

### Status

Setting	Description	Factory Default
Enable/Disabled	Enable or disable the static route.	None

**Name**

Setting	Description	Factory Default
10 characters	The name of the static route.	None

**Destination Address**

Setting	Description	Factory Default
Destination address	Specify the destination IP address.	None

**Netmask**

Setting	Description	Factory Default
Netmask	Specify the subnet mask for this IP address.	None

**Next Hop**

Setting	Description	Factory Default
Next hop	Specify the next router on the path to the destination IP.	None

**Metric**

Setting	Description	Factory Default
Metric	Specify the cost of the route.	None

**Delete a Static Route**

Select the entry from the list and click  to delete it.


**Modify an Existing Static Route**

Click  to modify the attributes and click **APPLY** to change the configuration.

## Routing Table

The Routing Table page shows all routing entries.

### Routing Table



Index	Type	Destination Address	Next Hop	Interface Name	Metric
1	connected	192.168.127.0/24	192.168.127.254	LAN	1
2	connected	192.168.127.0/28	192.168.127.254	LAN	1

1 - 2 of 2

# NAT Settings

## NAT Concept

NAT (Network Address Translation) is a common security function for changing the IP address during Ethernet packet transmission. When the user wants to hide the internal IP address (LAN) from the external network (WAN), the NAT function will translate the internal IP address to a specific IP address, or an internal IP address range to one external IP address. The benefits of using NAT include:


- The N-1 or Port forwarding NAT function hides the internal IP address of a critical network or device to increase the security of industrial network applications.
- NAT uses the same private IP address for different, but identical, groups of Ethernet devices. For example, 1-to-1 NAT makes it easy to duplicate or extend identical production lines.

**NOTE** The NAT function will check if incoming or outgoing packets match the policy. It starts by checking the packet with the first policy (Index=1); if the packet matches this policy, the Industrial NAT device will translate the address immediately and will then start checking the next packet. If the packet does not match this policy, it will check with the next policy.

**NOTE** The NAT-102 supports a maximum of 128 NAT policies.

## 1-to-1 NAT Overview


If the internal device and external device need to communicate with each other, choose 1-to-1 NAT, which offers bi-directional communication (N-to-1 and Port Forwarding are both unidirectional communication NAT functions).



1-to-1 NAT is usually used when you have a group of internal servers with private IP addresses that must connect to the external network. You can use 1-to-1 NAT to map the internal servers to public IP addresses. The IP address of the internal device will not change. 1-to-1 NAT will also create a corresponding secondary IP address (10.10.10.1) if the device is in the same subnet as the incoming interface.



The figure below illustrates how a user could extend production lines and use the same private IP addresses of internal devices in each production line. The internal private IP addresses of these devices will map to different public IP addresses. Configuring a group of devices for 1-to-1 NAT is easy and straightforward.



**1-to-1 NAT Settings in Production Line 1**

<input type="checkbox"/>	Status	Description	Index	Mode	Protocol	Incoming Interface	Src. IP:Port (Original Packet)	Dst. IP:Port (Original Packet)	Outgoing Interface	Src. IP:Port (Translated Packet)	Dst. IP:Port (Translated Packet)
<input checked="" type="checkbox"/>	Enabled	1-to-1_production_line_1-1	1	1-to-1		WAN	Any:Any	10.10.1.1:Any	All	Any:Any	192.168.100.1:Any
<input checked="" type="checkbox"/>	Enabled	1-to-1_production_line_1-2	2	1-to-1		WAN	Any:Any	10.10.1.2:Any	All	Any:Any	192.168.100.2:Any

**1- to-1 NAT Settings in Production Line 2**

<input type="checkbox"/>	Status	Description	Index	Mode	Protocol	Incoming Interface	Src. IP:Port (Original Packet)	Dst. IP:Port (Original Packet)	Outgoing Interface	Src. IP:Port (Translated Packet)	Dst. IP:Port (Translated Packet)
<input checked="" type="checkbox"/>	Enabled	1-to-1_production_line_2-1	1	1-to-1		WAN	Any:Any	10.10.2.1:Any	All	Any:Any	192.168.100.1:Any
<input checked="" type="checkbox"/>	Enabled	1-to-1_production_line_2-2	2	1-to-1		WAN	Any:Any	10.10.2.2:Any	All	Any:Any	192.168.100.2:Any

# 1-to-1 NAT

## Create a 1-to-1 NAT Entry

**Create Index 1**

Status \*

Description  
 0 / 128

Priority \*  
  
1 - 128

Mode

NAT Loopback  Double NAT

**Original Packet (Condition)**

Incoming Interface

Destination IP \*

**Translated Packet (Action)**

Destination IP \*

**Status**

Setting	Description	Factory Default
Enable/Disabled	Enable or disable the NAT policy.	Enabled

**Description**

Setting	Description	Factory Default
Description	Enter the name of the NAT rule.	None

**Priority**

Setting	Description	Factory Default
1 to 128	Enter the index of the NAT rule.	1

**NAT Mode**

Setting	Description	Factory Default
1-to-1	Select the NAT type.	1-to-1
N-to-1		
PAT		
Advance		

**NAT Loopback**

Setting	Description	Factory Default
Enable/Disabled	Enable or disable the NAT loopback function. Refer to <a href="#">NAT Loopback</a> for more information.	Disabled

**Double NAT**

Setting	Description	Factory Default
Enable/Disabled	Enable or disable the Double NAT function. Refer to <a href="#">Double NAT</a> for more information.	Disabled

**Original Packet (Condition)**

**Incoming Interface**

Setting	Description	Factory Default
All LAN WAN	Select the incoming interface for NAT rule.	LAN

**Destination IP**

Setting	Description	Factory Default
IP Address	Set the public IP address which the internal IP will be translated into.	0.0.0.0


**Translated Packet (Action)**

**Destination IP**

Setting	Description	Factory Default
IP Address	Specify the Internal IP address in LAN network area	0.0.0.0

**NAT Loopback**

Nat Loopback is designed to facilitate communication with service servers which have external IP translation within the same LAN segment. Consider the following scenario:



1. Host tries to access the web server via [www.xyz.com](http://www.xyz.com)
2. The DNS server replies the Web Server IP: 10.10.10.20
3. The Host will start to send the request packets to 10.10.10.20.

**With NAT Loopback disabled:**


- Because the request packet comes from Host, the incoming interface does not match any NAT rule.
- The NAT-102 will receive the request packet because the NAT rule has created secondary IP: 10.10.10.20.
- The NAT-102 sends the response packet to Host itself.
- Host will access the NAT-102's web page via [www.xyz.com](http://www.xyz.com).

**With NAT Loopback enabled:**

- The NAT-102 will forward the request packet from Host to the Web Server with Destination (from 10.10.10.20 to 192.168.127.20) and Source (from 192.168.127.10 to 10.10.10.20) IP translation.
- The Web Server sends the response packet to the NAT-102. The NAT-102 then forwards it to Host with Destination (from 10.10.10.20 to 192.168.127.10) and Source (from 192.168.127.20 to 10.10.10.20) IP translation.
- Host will correctly access the Web Server via [www.xyz.com](http://www.xyz.com).

<input type="checkbox"/>	Status	Description	Index	Mode	Protocol	Incoming Interface	Src. IP:Port (Original Packet)	Dst. IP:Port (Original Packet)	Outgoing Interface	Src. IP:Port (Translated Packet)	Dst. IP:Port (Translated Packet)
<input checked="" type="checkbox"/>	Enabled		1	1-to-1		LAN	Any:Any	10.10.10.20:Any	All	Any:Any	192.168.127.20:Any

**Bidirectional 1-to-1 NAT**




<input type="checkbox"/>	Status	Description	Index	Mode	Protocol	Incoming Interface	Src. IP:Port (Original Packet)	Dst. IP:Port (Original Packet)	Outgoing Interface	Src. IP:Port (Translated Packet)	Dst. IP:Port (Translated Packet)
<input checked="" type="checkbox"/>	Enabled		1	1-to-1		LAN	Any:Any	192.168.0.1:Any	All	Any:Any	10.0.0.1:Any
<input checked="" type="checkbox"/>	Enabled		2	1-to-1		WAN	Any:Any	10.0.0.100:Any	All	Any:Any	192.168.0.100:Any

For some applications, devices need to talk to both internal and external devices without using a gateway. Bidirectional 1-to-1 NAT can do Network Address Translation in both directions without needing a gateway.

**Double NAT**

The traditional bidirectional 1-to-1 NAT concept uses two 1-to-1 rules to facilitate two-way communication, as in the example below. With Double NAT, only 1-to-1 rule is necessary. The NAT-102 will automatically translate the incoming and outgoing addresses as if it was handling two separate rules, one for inbound and one for outbound. The main advantage of Double NAT is that it reduces the number of NAT rules and necessary IP addresses.

**Example**



**Bidirectional 1-to-1:**

- Two rule settings
- Two dedicated IPs

**1-to-1 with Double NAT**

- One rule setting
- One dedicated IP

<input type="checkbox"/>	Status	Description	Index	Mode	Protocol	Incoming Interface	Src. IP:Port (Original Packet)	Dst. IP:Port (Original Packet)	Outgoing Interface	Src. IP:Port (Translated Packet)	Dst. IP:Port (Translated Packet)
<input checked="" type="checkbox"/>	Enabled		1	1-to-1		LAN	Any:Any	10.0.0.100:Any	All	Any:Any	192.168.0.100:Any

**NOTE** The Industrial NAT device can obtain an IP address via DHCP or PPPoE. However, if this dynamic IP address is the same as the WAN IP for 1-to-1 NAT, then the 1-to-1 NAT function will not work. For this reason, we recommend disabling the DHCP/PPPoE when using the 1-to-1 NAT.

**N-to-1 NAT**

If the user wants to hide the Internal IP address from users outside the LAN, the easiest way is to use the N-to-1 (or N-1) NAT function. N-1 NAT replaces the source IP address with an external IP address and adds a logical port number to identify the connection of this internal/external IP address. This function is also called "Network Address Port Translation" (NAPT) or "IP Masquerading".

The N-1 NAT function is a one-way connection from an internal secure area to an external non-secure area. The user can initialize the connection from the internal to the external network but not the other way around.

**Create Index 1**

Status \*  
Enabled

Description  
0 / 128

Priority \*  
1  
1 - 128

Mode  
N-to-1

**Original Packet (Condition)**

Source IP: Start \*      Source IP: End \*  
0.0.0.0                      0.0.0.0

**Translated Packet (Action)**

Outgoing Interface  
All

CANCEL      APPLY

**Status**

Setting	Description	Factory Default
Enable/Disabled	Enable or disable the NAT policy.	Enabled

**Description**

Setting	Description	Factory Default
Description	Enter the name of the NAT rule.	None

**Priority**

Setting	Description	Factory Default
1 to 128	Enter the index of the NAT rule.	1

**NAT Mode**

Setting	Description	Factory Default
1-to-1 N-to-1 PAT Advance	Select the NAT type.	1-to-1

**Original Packet (Condition)****Source IP: Start**

Setting	Description	Factory Default
IP address	Specify the starting IP address of the source IP range.	0.0.0.0

**Source IP: End**

Setting	Description	Factory Default
IP address	Specify the ending IP address of the source IP range.	0.0.0.0

**Translated Packet (Action)****Outgoing Interface**


Setting	Description	Factory Default
All LAN WAN	Select the outgoing interface for the NAT rule.	All

## PAT (Port Address Translation)

If the initial connection is from outside the LAN, but the user still wants to hide the internal IP address, one way to do this is to use the PAT NAT function.

The user can specify the port number of an external IP address (WAN1 or WAN2) in the Port Forwarding policy list. For example, if the IP address of a web server in the internal network is 192.168.127.10 with port 80, the user can set up a Port Forwarding policy to let remote users connect to the internal web server from external IP address 10.10.10.10 through port 8080. The Industrial NAT device will transfer the packet to IP address 192.168.127.10 through port 80.

The PAT NAT function is one way of connecting from an external insecure area (WAN) to an internal secure area (LAN). The user can initiate the connection from the external network to the internal network, but not the other way around.



**Create a PAT NAT Entry**

**Create Index 1**

Status \*  
Enabled

Description  
0 / 128

Priority \*  
1  
1 - 128

Mode  
PAT

Protocol

NAT Loopback Disabled Double NAT Disabled

**Original Packet (Condition)**

Incoming Interface  
All

Destination Port \*  
0  
1 - 65535

**Translated Packet (Action)**

Destination IP \*  
0.0.0.0

Destination Port \*  
0  
1 - 65535

CANCEL APPLY

<input type="checkbox"/>	Status	Description	Index	Mode	Protocol	Incoming Interface	Src. IP:Port (Original Packet)	Dst. IP:Port (Original Packet)	Outgoing Interface	Src. IP:Port (Translated Packet)	Dst. IP:Port (Translated Packet)
<input type="checkbox"/>	Enabled		1	PAT	TCP	WAN	Any:Any	Dynamic:8080	All	Any:Any	192.168.127.10:80

**Enable**

Setting	Description	Factory Default
Enable/Disabled	Enable or disable the NAT policy.	Enabled

**Description**

Setting	Description	Factory Default
---------	-------------	-----------------

Description	Enter the name of the NAT rule.	None
-------------	---------------------------------	------

**Priority**

Setting	Description	Factory Default
1 to 128	Enter the index of the NAT rule.	1



**NAT Mode**

Setting	Description	Factory Default
1-to-1 N-to-1 PAT Advance	Select the NAT type.	1-to-1

**Protocol**

Setting	Description	Factory Default
ICMP TCP UDP	Select the NAT policy protocol.	None

**NAT Loopback**

Setting	Description	Factory Default
Enable/Disabled	Enable or disable the NAT loopback function. Refer to <a href="#">NAT Loopback</a> for more information.	Disabled

**Double NAT**

Setting	Description	Factory Default
Enable/Disabled	Enable or disable the Double NAT function. Refer to <a href="#">Double NAT</a> for more information.	Disabled

**Original Packet (Condition)****Incoming Interface**

Setting	Description	Factory Default
All LAN WAN	Select the interface for the NAT policy.	LAN

**Destination Port**

Setting	Description	Factory Default
1 to 65535	Specify the destination port number.	0

**Translated Packet (Action)****Destination IP**

Setting	Description	Factory Default
IP Address	Specify the translated IP address in the internal network.	0.0.0.0

**Destination Port**

Setting	Description	Factory Default
1 to 65535	Specify the translated port number in the internal network.	0

# Advance

The Advance NAT function opens up all available options to advanced users to customize their own settings.

### Create Index 1

Status \*  
Enabled

Description  
0 / 128

Priority \*  
1  
1 - 128

Mode  
Advance

Protocol

#### Original Packet (Condition)

Incoming Interface  
All

Source IP Mapping Type  
Any

Source Port Mapping Type  
Any

Destination IP Mapping Type  
Any

Destination Port Mapping Type  
Single

Destination Port \*  
0  
1 - 65535

#### Translated Packet (Action)

Outgoing Interface  
All

Source IP Mapping Type  
Any

Source Port Mapping Type  
Any

Destination IP Mapping Type  
Single

Destination IP \*  
0.0.0.0

Destination Port Mapping Type  
Single

Destination Port \*  
0  
1 - 65535

CANCEL APPLY

**Enable**

Setting	Description	Factory Default
Enable/Disabled	Enable or disable the NAT policy.	Enabled

**Description**

Setting	Description	Factory Default
Description	Enter the name of the NAT rule.	None

**Priority**

Setting	Description	Factory Default
1 to 128	Enter the index of the NAT rule.	1

**NAT Mode**

Setting	Description	Factory Default
1-to-1 N-to-1 PAT Advance	Select the NAT type.	1-to-1

**Protocol**

Setting	Description	Factory Default
ICMP TCP UDP	Select the NAT policy protocol.	None

**Original Packet (Condition)****Incoming Interface**

Setting	Description	Factory Default
All LAN WAN	Select the interface for the NAT policy.	All

**Source IP Mapping Type**

Setting	Description	Factory Default
Any Single Range Subnet mask	Select the source IP mapping type.	Any

**Source Port Mapping Type**

Setting	Description	Factory Default
Any Single Range	Select the source port mapping type.	Any

**Destination IP Mapping Type**

Setting	Description	Factory Default
Any Single Range Subnet mask	Select the destination IP mapping type.	Any

**Destination Port Mapping Type**

Setting	Description	Factory Default
Any Single Range	Select the destination port mapping type.	Single

**Destination Port**

Setting	Description	Factory Default
1 to 65535	Specify the destination port number.	0

**Translated Packet (Action)****Outgoing Interface**

Setting	Description	Factory Default
All LAN WAN	Select the interface for the NAT policy.	All

**Source IP Mapping Type**

Setting	Description	Factory Default
Any Single Range Subnet mask Dynamic	Select the source IP mapping type.	Any

**Source Port Mapping Type**

Setting	Description	Factory Default
Any Single Range	Select the source port mapping type.	Any

**Destination IP Mapping Type**

Setting	Description	Factory Default
Any Single Range Subnet mask	Select the destination IP mapping type.	Single

**Destination IP**

Setting	Description	Factory Default
IP Address	Specify the translated IP address in the internal network.	0.0.0.0

**Destination Port Mapping Type**

Setting	Description	Factory Default
Any Single Range	Select the destination port mapping type.	Single

**Destination Port**


Setting	Description	Factory Default
1 to 65535	Specify a translated port number in the internal network.	0

The following topics are covered in this chapter:

- ❑ **Policy Concept**
- ❑ **Layer 3 Policy**
  - Create a New Firewall Policy
  - Automation Profile

# Policy Concept

A firewall device is commonly used to provide secure traffic control over an Ethernet network, as illustrated in the following figure. Firewall devices are deployed at critical points between an external network (the non-secure part) and an internal network (the secure part).



# Layer 3 Policy

The Industrial NAT device's firewall policy provides secure traffic control and allows users to have more control over network traffic based on certain parameters.

**Layer 3 Policy**

Firewall Event Log: Disabled

Malformed Packets: Disabled | Severity: <0> Emergency |  Local Storage |  Syslog Server

**APPLY**

	Index	Status	Name	Protocol	Incoming Interface	Outgoing Interface	Src. IP:Port	Dst. IP:Port	Action	Event Log/Severity
<input type="checkbox"/>	1	Disabled		All	Any	Any	All:All	All:All	DROP	Disable / <0> Emergency

Max 32 | 1 - 1 of 1

**APPLY**

## Firewall Event Log

If enabled, the Industrial NAT device keeps real-time event logs for different types of firewall events. You can choose to save these logs locally or send them to the Syslog server.

## Malformed Packets

Enable this option to have the system record event logs when malformed packets are dropped. These logs can be stored locally or be sent to a syslog server. You can also adjust the severity of these events.

## Create a New Firewall Policy

Click **+** to create a new firewall policy.

### Create Index 2

Index  
2

Status  
Enabled

Name  
0 / 64

Severity  
<0> Emergency  Local Storage  Syslog Server

From Interface  
All

To Interface  
All

Automation Profile  
All

Filter Mode  
IP Address Filter

Action Profile  
ACCEPT

Source IP  
All

Source Port  
All

Destination IP  
All

Destination Port  
All

**Index**

The index number is generated automatically.

**Status**

Setting	Description	Factory Default
Enable/Disable	Enable or disable the firewall policy.	Enabled

**Name**

Setting	Description	Factory Default
Custom string	Enter a name for the firewall rule.	None

**Severity**

Setting	Description	Factory Default
<0> Emergency <1> Alert <2> Critical <3> Error <4> Warning <5> Notice <6> Informational <7> Debug	Select the severity of firewall event.	<0> Emergency

**Local Storage**

Setting	Description	Factory Default
Check/Uncheck	When checked, the firewall white/blacklist rule event logs are stored in the local storage and will show in "Event Log" table.	Unchecked

**Syslog Server**

Setting	Description	Factory Default
Check/Uncheck	When checked, firewall white/blacklist rule event logs are sent to a Syslog server.	Unchecked

**From Interface**

Setting	Description	Factory Default
All LAN WAN Any	Select the From interface.	All

**To Interface**

Setting	Description	Factory Default
All LAN WAN Any	Select the To interface.	All

**Automation Profile**

Setting	Description	Factory Default
Refer to the <a href="#">Automation Profile</a> section.	Select the Protocol parameters for the firewall policy.	None

**Filter Mode**

Setting	Description	Factory Default
IP Address Filter	The firewall policy will filter based on IP address.	IP Address Filter



Source MAC Filter	The firewall policy will filter based on MAC address and source. This mode is disabled and its functionality is replaced by the "Port Security/Device Lockdown" feature instead.	
-------------------	--	--

**Action Profile**

Setting	Description	Factory Default
Accept	The packet will be allowed through if it matches the firewall policy.	Accept
Drop	The packet will be denied if it matches the firewall policy.	

**Source IP**

Setting	Description	Factory Default
All	The firewall policy will check all source IP addresses in the packet.	All
Single	The firewall policy will check for a single specified source IP address in the packet.	
Range	The firewall policy will check for source IP addresses in the packet within the specified range.	

**Source Port**

Setting	Description	Factory Default
All	The firewall policy will check all source port numbers in the packet.	All
Single	The firewall policy will check for a single specified source port number in the packet.	
Range	The firewall policy will check for source port numbers in the packet within the specified range.	

**Destination IP**

Setting	Description	Factory Default
All	The firewall policy will check all destination IP addresses in the packet.	All
Single	The firewall policy will check for a single specified destination IP address in the packet.	
Range	The firewall policy will check for destination IP addresses in the packet within the specified range.	


**Destination Port**

Setting	Description	Factory Default
All	The firewall policy will check all destination port numbers in the packet.	All
Single	The firewall policy will check for a single specified destination port number in the packet.	
Range	The firewall policy will check for destination port numbers in the packet within the specified range.	

**NOTE** The Industrial NAT device's firewall function will check if incoming or outgoing packets match the firewall policy. It starts by matching the packet to the first policy (Index = 1); if the packet matches this policy, it will accept the packet immediately and then check the next packet. If the packet does not match this policy, it will match it with the next policy.

**NOTE** The NAT-102 supports a maximum of 32 firewall policies.

### Delete a Firewall Policy

Select the policy from the list and click  to delete it.


### Modify a Firewall Policy

Click  to modify the attributes and click **APPLY** to change the configuration.

## Automation Profile

Ethernet Fieldbus protocols are popular in industrial automation applications. In fact, many Fieldbus protocols (e.g., EtherNet/IP and Modbus TCP/IP) can operate on an industrial Ethernet network, with the Ethernet port number defined by IANA (Internet Assigned Numbers Authority). The Industrial NAT device supports the **Automation Profile** feature, which includes 45 different pre-defined profiles (Modbus TCP/IP, Ethernet/IP, etc.), allowing users to create an industrial Ethernet Fieldbus firewall policy with just a single click.

For example, if the you want to create a Modbus TCP/IP firewall policy for an internal network, you just need to select the **TCP** or **UDP** protocol from the **Automation Profile** drop-down menu on the **Create a New Firewall Policy** page.



The screenshot shows the configuration interface for a firewall policy. The title is "Create Index 2". The "Index" field is set to "2". The "Status" is "Enabled". The "Name" field is empty with a "0 / 64" character count. The "Severity" is set to "<0> Emergency". There are checkboxes for "Local Storage" and "Syslog Server", both of which are unchecked. The "From Interface" and "To Interface" are both set to "All". The "Automation Profile" dropdown menu is highlighted with a red box and currently shows "All". Below this, the "Filter Mode" is "IP Address Filter", the "Action Profile" is "ACCEPT", the "Source IP" is "All", the "Source Port" is "All", and the "Destination IP" is "All". At the bottom right, there are "CANCEL" and "APPLY" buttons.

The following table shows the Automation Profile for Ethernet Fieldbus Protocol and the corresponding port number:

<b>Ethernet Fieldbus Protocol</b>	<b>Port Number</b>
TCP	34980
UDP	34980
ICMP	N/A
EtherNet/IP I/O (TCP)	2222
EtherNet/IP I/O (UDP)	2222
EtherNet/IP messaging (TCP)	44818
EtherNet/IP messaging (UDP)	44818
FF Annunciation (TCP)	1089
FF Annunciation (UDP)	1089
FF Fieldbus Message Specification (TCP)	1090
FF Fieldbus Message Specification (UDP)	1090
FF System Management (TCP)	1091
FF System Management (UDP)	1091
FF LAN Redundancy Port (TCP)	3622
FF LAN Redundancy Port (UDP)	3622
LonWorks (TCP)	2540
LonWorks (UDP)	2540
LonWorks2 (TCP)	2541
LonWorks2 (UDP)	2541
Modbus TCP/IP (TCP)	502
Modbus TCP/IP (UDP)	502
PROFINet RT Unicast (TCP)	34962
PROFINet RT Unicast (UDP)	34962
PROFINet RT Multicast (TCP)	34963
PROFINet RT Multicast (UDP)	34963
PROFINet Context Manager (TCP)	34964
PROFINet Context Manager (UDP)	34964
IEC 60870-5-104 process control over IP (TCP)	2404
IEC 60870-5-104 process control over IP (UDP)	2404
DNP3 (TCP)	20000
DNP3 (UDP)	20000

The Automation Profile also includes entries for other commonly used Ethernet protocols listed in the following table:

<b>Ethernet Protocol</b>	<b>Port Number</b>
IPsec NAT-Traversal (TCP)	4500
IPsec NAT-traversal (UDP)	4500
FTP-data (TCP)	20
FTP-data (UDP)	20
FTP-control (TCP)	21
FTP-control (UDP)	21
SSH (TCP)	22
SSH (UDP)	22
Telnet (TCP)	23
Telnet (UDP)	23
HTTP (TCP)	80
HTTP (UDP)	80
IPsec (TCP)	1293
IPsec (UDP)	1293
L2TP (TCP)	1701
L2TP (UDP)	1701

<b>Ethernet Protocol</b>	<b>Port Number</b>
PPTP (TCP)	1723
PPTP (UDP)	1723
RADIUS (TCP)	1812
RADIUS (UDP)	1812
RADIUS Accounting (TCP)	1813
RADIUS Accounting (UDP)	1813
Ethercat (TCP)	34980
Ethercat (UDP)	34980

For the purposes of this document, certificate management refers to the X.509 SSL certificate. X.509 is a digital certificate method commonly used for IPsec, OpenVPN, and HTTPS authentication. The Industrial NAT device can act as a Root CA (Certificate Authority) and issue a trusted Root Certificate. Alternatively, users can import certificates from other CAs into the Industrial NAT device.

Certificates are a time-based authentication mechanism. Before processing certificates, make sure the Industrial NAT device's clock is synced properly. For more details regarding system time synchronization, refer to the [Time](#) section.

The following topics are covered in this chapter:

❑ **Device Security**

- Login Policy
- Trusted Access
- SSH & SSL

❑ **Network Security**

- Port Security

# Device Security

## Login Policy

### Login Policy

Login Message  
  
0 / 512

Login Authentication Failure Message  
  
0 / 512

Login Failure Account Lockout  
Disabled ▼

Login Failure Retry Threshold \*  
  
1 - 10 times

Lockout Duration \*  
  
1 - 10 min

Auto Logout After \*  
  
0 - 1440 min

APPLY

### Login Message

Setting	Description	Factory Default
Max. 512 characters	Enter a welcome message that will appear when users log in to the device.	None

### Login Authentication Failure Message

Setting	Description	Factory Default
Max. 512 characters	Enter a message that will appear if the user failed to log in.	None

### Login Failure Account Lockout

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the lockout function which will temporarily prevent users from logging in after several failed login attempts.	Disabled

### Login Failure Retry Threshold

Setting	Description	Factory Default
1 to 10 times	Specify the number of login retry attempts before the user is locked out.	5

### Lockout Duration

Setting	Description	Factory Default
1 to 10 minutes	Specify the lockout duration.	5

### Auto Logout After

Setting	Description	Factory Default
Max. 1440 minutes	When the user is idle for the specified duration, the user will be automatically logged out from the device. The default duration is 5 minutes.	5

# Trusted Access

The NAT device uses an IP address-based filtering method to control access.

### Trusted Access

Trusted IP List (Disabling this will allow all IP connections)  
 Enabled ▼

Accept All LAN Port Connections  
 Enabled ▼

Log ▼ Severity ▼  Local Storage  Syslog Server  
 Disabled ▼ <0> Emergency

**APPLY**

---

+ ☰
Search

<input type="checkbox"/>	Index	Status	IP Address	Netmask
Max 10				0 of 0

**APPLY**

## Enable Logging Trusted Access Events

To enable the Trusted Access event log function, select set the Log option to Enable and check either or both the Local Storage or Syslog Server options. You may also define the severity of the Trusted Access types and record it in the event.

## Create a Trusted Access Entry

You can control which IP addresses can have access to the Moxa industrial NAT device by adding them to the Trusted Access list. If enabled, only addresses on the list will be allowed access to the Moxa industrial NAT device.

Click **+** to add an IP address to the Trusted Access list.

### Create Index 1

Index  
 1|

Status \*  
 Enabled ▼

IP Address \*  
 \_\_\_\_\_

Netmask \*  
 \_\_\_\_\_

CANCEL **APPLY**


Each IP address and netmask entry can be tailored for different situations, for example:

- Grant access to one host with a specific IP address**  
 For example, enter IP address 192.168.1.1 with netmask 255.255.255.255 to allow access to 192.168.1.1 only.
- Grant access to any host on a specific subnetwork**  
 For example, enter IP address 192.168.1.0 with netmask 255.255.255.0 to allow access to all IPs on the subnet defined by this IP address/netmask combination.
- Grant access to all hosts**  
 Disable the Trusted Access list. Select **Disabled** in **Trusted IP List (Disabling this will allow all IP connections)**.

The following table shows additional configuration examples:

Hosts That Need Access	Input Format
Any host	Disable
192.168.1.120	192.168.1.120 / 255.255.255.255
192.168.1.1 to 192.168.1.254	192.168.1.0 / 255.255.255.0
192.168.0.1 to 192.168.255.254	192.168.0.0 / 255.255.0.0
192.168.1.1 to 192.168.1.126	192.168.1.0 / 255.255.255.128
192.168.1.129 to 192.168.1.254	192.168.1.128 / 255.255.255.128

### Delete a Trusted Access Entry

Select the entry from the Trusted Access List and click  to delete it.


### Modify a Trusted Access Entry

Click  to modify the attributes and click **APPLY** to change the configuration.

## SSH & SSL

### SSH

The NAT device will generate a SSH certificate automatically by default. If not, click **REGENERATE** to regenerate the SSH host key.





## SSL

On the SSL screen, you can generate an SSL certificate.

### SSH & SSL

SSH

SSL

Local Certificate

Certificate Source  
 Auto Generate ▼

---

Regenerate SSL Certificate  
 Disabled ▼

---

Created on  
 Oct 28 21:13:32 2021 GMT

---

Expiration Date  
 Oct 24 21:13:32 2036 GMT

---

### Certificate Source

Setting	Description	Factory Default
Auto Generate	The NAT device will generate a certificate automatically. If not, select "Enabled" in Regenerate SSL Certificate to generate a certificate.	Auto Generate
Local Certificate Database	Select the certificate you want to import into Local Certificate Database. The certificate that can be loaded here is limited to "Certificate from CSR" and "Certificate From PKCS#12".	

### Regenerate SSL Certificate

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable SSL Key regeneration.	Disabled

## Local Certificate

You can manually import certificates to the Industrial NAT device.


### Import Identity Certificate

Setting	Description	Factory Default
Certificate, Certificate from PKCS#12	Select the type of certificate. Valid certificates must have the .crt file extension. Certificate from PKCS#12 must have the .p12 file extension.	Certificate

### Label

Setting	Description	Factory Default
Max. 30 characters	Enter a label for the certificate.	None

### Select Certificate

Setting	Description	Factory Default
Select Certificate	Click  and select the certificate you want to import. The certificate that can be loaded here is limited to "Certificate from CSR" and "Certificate From PKCS#12".	None

# Network Security

## Port Security

### Device Lockdown

Device Lockdown provides an easy way to automatically establish firewall whitelisting. Users do not need to know the device IP or MAC to establish firewall rules. The Learning function allows the device to learn device information through network traffic to set up whitelisting rules.

### Port Security

Device Lockdown

Learning Status  
Standby

START LEARNING
STOP LEARNING

Status  
Disabled

Auto Learning on Startup: Disabled      Learning Period\*: 180  
30 - 86400 sec

Interface

Lockdown Mode  
MAC Address

Log: Disabled      Severity: <4> Warning      Log Destination: Local Storage

APPLY

↻

Description	Network Access	IP Address	MAC Address	Interface	Entry From
Default Rule	Block	Any	Any		Auto Learned

Max 65
Items per page: 50      1 - 1 of 1      |< < > >|

### Manual Learning

Click **START LEARNING** to have the device learn the whitelist information from ARP tables through network traffic. Click **STOP LEARNING** to stop the process.

## Configure Automatic Learning

### Status

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable the automatic learning function.	Disabled

### Auto Learning on Startup

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable auto learning on startup.	Disabled

### Learning Period

Setting	Description	Factory Default
30 to 86400 seconds	Specify the duration auto learning will be enabled for.	180

### Interface

Setting	Description	Factory Default
LAN/WAN	Select an interface to lock down. Only one interface can be locked down at any given time.	None

### Lockdown Mode

Setting	Description	Factory Default
MAC Address, MAC+IP Access	Select the firewall filtering criteria.	MAC Address

### Log

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable device lockdown event logs.	Disabled

### Severity

Setting	Description	Factory Default
<0> Emergency <1> Alert <2> Critical <3> Error <4> Warning <5> Notice <6> Informational <7> Debug	Select the severity of device lockdown events.	<4> Warning

### Log Destination

Setting	Description	Factory Default
Local Storage/Syslog Server	Choose to store device lockdown event logs locally or send them to a Syslog server.	Local Storage

# 10

## Diagnostics

---

Through the Diagnostics section, you can keep track of the system and network performance, consult event logs, and check the status of the port connectors.

The Industrial NAT device also provides **Ping** tools for administrators to diagnose network systems.

The following topics are covered in this chapter:

### ❑ **System Status**

- Resource Utilization

### ❑ **Log & Event Notification**

- Event Log
- Event Notification
- Syslog
- Email Notifications


### ❑ **Tools**


- Ping

# System Status

## Resource Utilization

On this page, you can view the system resource utilization history, including current and historical CPU and memory usage.

Click  to refresh the information.



# Log & Event Notification

## Event Log

### Event Log

#### Event Log

Event Log

Threshold Settings

Oversize-Action

Overwrite the oldest event log ▼

APPLY

🔄
🗑️
📄

Index	Timestamp	Function	Severity	Message
1	2021/11/1 9:56:21+0:00	System	Emergency	[Configuration Change] NAT, Bootup:3, Startup:0d0h17m58s
2	2021/11/1 9:53:55+0:00	System	Emergency	[Configuration Change] Static Route, Bootup:3, Startup:0d0h15m31s
3	2021/11/1 9:53:15+0:00	System	Emergency	[Configuration Change] Static Route, Bootup:3, Startup:0d0h14m52s
4	2021/11/1 9:39:10+0:00	System	Emergency	[Auth Ok, Login Success] Account (admin), Bootup:3, Startup:0d0h0m47s
5	2021/11/1 9:38:56+0:00	System	Emergency	[Auth Fail] Account (admin), Bootup:3, Startup:0d0h0m33s
6	2021/11/1 9:38:51+0:00	System	Emergency	[Cold Start] Bootup:3, Startup:0d0h0m28s
7	2021/11/1 9:38:50+0:00	System	Emergency	[Link On] Port 1, Bootup:3, Startup:0d0h0m27s
8	2021/10/29 17:31:58+0:00	System	Emergency	[Configuration Change] VLAN, Bootup:2, Startup:0d1h8m27s
9	2021/10/29 17:30:30+0:00	System	Emergency	[Configuration Change] VLAN, Bootup:2, Startup:0d1h6m59s
10	2021/10/29 17:30:19+0:00	System	Emergency	[Configuration Change] VLAN, Bootup:2, Startup:0d1h6m48s

#### Oversize-Action

Setting	Description	Factory Default
Overwrite the oldest event log, Stop recording event logs	Select the oversize action when the log storage is full.	Overwrite the oldest event log

Click to refresh the event logs.

Click to delete all logs.

Click to export all logs to a file.

## Threshold Settings

In the Threshold Settings screen, you can set up an early warning that triggers when the log storage has exceeded the specified storage threshold.

### Event Log

Event Log
Threshold Settings

Capacity Warning

Disabled i

Warning Threshold

50

50 - 100 %

Method

Email

APPLY

### Capacity Warning

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable capacity warning. The Registered Action can be configured for individual events by editing the event on the Event Notifications page.	Disabled

### Warning Threshold

Setting	Description	Factory Default
50 to 100 %	Enter the threshold percentage of the current storage. Once the storage exceeds this value, the warning will trigger.	50

### Method

Setting	Description	Factory Default
Email	Choose how the warning is sent.	Email

## Event Notification

### System

System Events are related to the overall function of the device. Each event can be activated independently with different warning approaches. Administrator also can decide the severity of each system event.



### Event Notifications

System
Port

Status	Event Name	Severity	Registered Action
Disabled	Cold Start	EMERG	
Disabled	Warm Start	EMERG	
Disabled	Config. Change	EMERG	
Disabled	Auth. Failure	EMERG	

1 - 4 of 4
< >

Click to modify the System Event Notification.

#### Edit Event Notification

Event Name

Status  
Disabled ▼

Registered Action  
 ▼

Severity  
EMERG ▼

CANCEL
APPLY

**Event Name**

Setting	Description
Cold Start	The power input was cut off and then reconnected.
Warm Start	The device was rebooted, such as when network parameters are changed (IP address, subnet mask, etc.).
Config. Change	A configuration item has been changed.
Auth. Failure	An incorrect username or password was entered.

**Status**

Setting	Description	Factory Default
Enable/Disabled	Enable or disable system event notifications.	Disabled

**Registered Action**

There are two response actions available on the NAT Series when events are triggered.

Setting	Description	Factory Default
E-Mail	The device will send a notification to the email server defined in the Email Setting section.	None
Syslog	The device will record the event on the syslog server defined in the Syslog Server Setting section.	

**Severity**

Setting	Description	Factory Default
EMERG	System is unusable	EMERG
ALERT	Action must be taken immediately	
CRIT	Critical conditions	
ERROR	Error conditions	
WARN	Warning conditions	
NOTICE	Normal but significant condition	
INFO	Informational messages	
DEBUG	Debug-level messages	

**Port**

Port Events are related to the activity of a specific port.


**Event Notifications**

System
Port

Enable	Port Name	Link-On	Link-Off	Severity	Registered Action
Disabled	1	Disabled	Disabled	EMERG	
Disabled	2	Disabled	Disabled	EMERG	

1 - 2 of 2
< >

### Modify a Port Event Notification

Click  to modify the Port Event Notification.

**Edit Event Notification**

Port Name  
1

---

Enabled  
Disabled ▼

Link-On  
Disabled ▼

Link-Off  
Disabled ▼

Registered Action  
▼

Severity  
EMERG ▼

CANCEL APPLY

**Port Name**

This is the physical port (1 or 2) on the NAT-102 device.

**Status**

Setting	Description	Factory Default
Enable/Disabled	Enable or disable event notifications for the port.	Disabled

**Link-On**

Setting	Description	Factory Default
Enable/Disabled	If enabled, an event is triggered when the port is connected to another device.	Disabled

**Link-Off**

Setting	Description	Factory Default
Enable/Disabled	If enabled, an event is triggered when the port is disconnected (e.g., the cable is pulled out, or the connected device is shut down).	Disabled

**Registered Action**

There are two response actions available on the NAT series when events are triggered.

Setting	Description	Factory Default
E-Mail	The device will send a notification to the email server defined in the Email Setting section.	None
Syslog	The device will record the event on the syslog server defined in the Syslog Server Setting section.	

**Severity**

Setting	Description	Factory Default
EMERG	System is unusable	EMERG
ALERT	Action must be taken immediately	
CRIT	Critical conditions	

Setting	Description	Factory Default
ERROR	Error conditions	
WARN	Warning conditions	
NOTICE	Normal but significant condition	
INFO	Informational messages	
DEBUG	Debug-level messages	

## Syslog

### Syslog

Syslog Server 1

Disabled ▼

---

Address 1 UDP Port

514

1 - 65535

Syslog Server 2

Disabled ▼

---

Address 2 UDP Port

514

1 - 65535

Syslog Server 3

Disabled ▼

---

Address 3 UDP Port

514

1 - 65535

APPLY

### Syslog Server 1/2/3

Setting	Description	Factory Default
Enabled/Disabled	Enable or disable syslog server 1/2/3.	Disabled

### Address 1/2/3

Setting	Description	Factory Default
Address 1/2/3	Enter the IP address of Syslog server 1/2/3.	None

### UDP Port

Setting	Description	Factory Default
1 to 65535	Enter the UDP port of Syslog server 1/2/3.	514

**NOTE** The following events will be recorded into the Moxa industrial NAT device’s Event Log table, and will then be sent to the specified Syslog Server:

- Cold start
- Warm start
- Configuration change activated
- Authentication fail
- Port link on/off

# Email Notifications

### Email Notifications

Mail Server 0 / 60

---

TCP Port

25

---

1 - 65535

Username 0 / 60

---

Password 0 / 60

---

Sender Address 0 / 60

---

1st Recipient Email Add... 0 / 60

---

2nd Recipient Email Ad... 0 / 60

---

3rd Recipient Email Add... 0 / 60

---

4th Recipient Email Add... 0 / 60

---

APPLY
Send Test Email

**Mail Server**

Setting	Description	Factory Default
Max. 60 characters	The email server address.	None

**TCP Port**

Setting	Description	Factory Default
1 to 65535	The TCP port of the email server.	25

**Username**

Setting	Description	Factory Default
Max. 60 characters	The username used to log in to the email server.	None

**Password**

Setting	Description	Factory Default
Max. 60 characters	The password used to log in to the email server.	None

**Sender Address**

Setting	Description	Factory Default
Max. 60 characters	Enter the sender's email address.	None

**1st/2nd/3rd/4th Recipient Email Address**

Setting	Description	Factory Default
Max. of 60 characters	You can set up to 4 email addresses to receive alarm emails from the NAT device.	None

**Send Test Email**

After you complete the email settings, click **APPLY** to apply the settings first and then press the **Send Test Email** button to verify that the settings are working correctly.


**NOTE** Auto warning e-mail messages will be sent through an authentication-protected SMTP server that supports the CRAM-MD5, LOGIN, and PLAIN methods of SASL (Simple Authentication and Security Layer) authentication mechanism.

We strongly recommend not entering your account name and password if auto warning e-mail messages are delivered without an authentication mechanism.

## Tools


### Ping

The Ping function uses the ping command to give you a simple but powerful tool for troubleshooting network problems.

Enter the target IP address or domain name you want to ping in the IP Address/Domain Name field and click **PING**. Click  to expand the results of the ping test to identify any possible problems.

#### Ping

Ping result 

# Account Privileges List

This appendix lists the privileges for the different account roles.

## User Role Privileges

The following table lists the privileges of the different user roles for the functions of the device.

The table uses the follow letter designations:

- **R**: Read-only privilege
- **W**: Write privilege
- **R/W**: Read/write privilege

<b>Function</b>	<b>Account Privilege</b>		
<b>System</b>	<b>Admin</b>	<b>Supervisor</b>	<b>User</b>
System Management			
- Device Information	R/W	R/W	R
- Firmware Upgrade	R/W	R/W	R
- Configuration Backup and Restore	R/W	R/W	R
- Restore	R/W	R/W	R
Account Management			
- User Account	R/W	R	R
- Password Policy	R/W	R/W	R
Management Interface			
- User Interface	R/W	R/W	R
Time			
- System Time	R/W	R/W	R
- Time Zone	R/W	R/W	R
<b>Network Configuration</b>	<b>Admin</b>	<b>Supervisor</b>	<b>User</b>
Port			
- Port Settings	R/W	R/W	R
Layer 2 Switching			
- VLAN	R/W	R/W	R
- MAC Address Table	R	R	R
Layer 3 Interface	R/W	R/W	R
<b>Network Service</b>	<b>Admin</b>	<b>Supervisor</b>	<b>User</b>
DHCP Server	R/W	R/W	R
<b>Routing &amp; NAT</b>	<b>Admin</b>	<b>Supervisor</b>	<b>User</b>
Unicast Routing			
- Static Routes	R/W	R/W	R
- Routing Table	R	R	R
NAT Setting	R/W	R/W	R
<b>Firewall</b>	<b>Admin</b>	<b>Supervisor</b>	<b>User</b>
Layer 3 Policy	R/W	R/W	R

<b>Security</b>	<b>Admin</b>	<b>Supervisor</b>	<b>User</b>
Device Security			
- Login Policy	R/W	R/W	R
- Trusted Access	R/W	R/W	R
- SSH & SSL	R/W	R/W	R
Network Security			
- Port Security	R/W	R/W	R
<b>Diagnosis</b>	<b>Admin</b>	<b>Supervisor</b>	<b>User</b>
System Status			
- Resource Utilization	R/W	R/W	R
Log & Event Notification			
- Event Log	R/W	R/W	R
- Event Notifications	R/W	R/W	R
- Syslog	R/W	R/W	R
- Email Notifications	R/W	R/W	R
Tools			
- Ping	R/W	R/W	R